





編號	品名	數量	品號
1	上爪塊	1	LSW16-A01
2	下爪塊	1	LSW16-A02
3	三角推塊	1	LSW16-A03
4	定位插銷	2	LSW16-A04
5	推塊拉柄	1	LSW16-A05
6	主軸拉柄	1	LSW16-A06
7	加高墊塊	1	LSW16-A07
8A	握把片-A	1	LSW16-A08A
8B	握把片-B	1	LSW16-A08B
9	握把華司	2	LSW16-A09
10	握把桿	1	LSW16-A10
11	支撐墊塊組	1	LSW16-AA2
12	皿型螺栓	2	XNFM08-12
13	華司	3	XW-M06
14	半圓頭螺栓	3	XNBHM06-16
15	螺栓	2	XNSETM06-16
16	螺栓	2	XNSETM06-10
17	螺栓	2	XNSETM04-12
18	螺栓	2	XNCAPM04-16
19	螺栓	1	XNBHM06-12
20	螺栓	2	XNBHM08-16
21	舉動千斤頂	1	RSC-102

*修理包



Item	Description	Qty	Part No.
1	Upper Jaw	1	LSW16-A01
2	Lower Jaw	1	LSW16-A02
3	Drive Wedge	1	LSW16-A03
4	slide pins	2	LSW16-A04
5	Tail	1	LSW16-A05
6	push pin	1	LSW16-A06
7	lifting wedge stepped block	1	LSW16-A07
8A	handle slide plates	1	LSW16-A08A
8B	handle slide plates	1	LSW16-A08B
9	washer	2	LSW16-A09
10	handle bar	1	LSW16-A10
11	safety block	1	LSW16-AA2
12	screws	2	XNFM08-12
13	washer	3	XW-M06
14	screws	3	XNBHM06-16
15	screws	2	XNSETM06-16
16	screws	2	XNSETM06-10
17	screws	2	XNSETM04-12
18	screws	2	XNCAPM04-16
19	screw	1	XNBHM06-12
20	screws	2	XNBHM08-16
21	cylinder	1	RSC-102

* repair kit

* repair kit