



編號	品名	數量	3/4"	7/8"	1"	M20	M22	M24	M27
			品號	品號	品號	品號	品號	品號	品號
1	油壓缸	1	SBT20-B01	SBT20-B01	SBT20-B01	SBT20-B01	SBT20-B01	SBT20-B01	SBT20-B01
2	主軸	1	SBT20-B02	SBT20-B02	SBT20-B02	SBT20-B02	SBT20-B02	SBT20-B02	SBT20-B02
3	螺牙帽	1	SBT-20T 3/4"	SBT-20T 7/8"	SBT-20T 1"	SBT-20T M20	SBT-20T M22	SBT-20T M24	SBT-20T M27
4	架橋	1	SBT-20J	SBT-20J	SBT-20J	SBT-20J	SBT-20J	SBT-20J	SBT-20J
5	六角套筒	1	SBT-20H 32	SBT-20H 36	SBT-20H 41	SBT-20H 30	SBT-20H 32	SBT-20H 36	SBT-20H 41
6	螺栓	3	XNSETM06-12-N	XNSETM06-12-N	XNSETM06-12-N	XNSETM06-12-N	XNSETM06-12-N	XNSETM06-12-N	XNSETM06-12-N
* 7	背托環	1	SBT20-B07	SBT20-B07	SBT20-B07	SBT20-B07	SBT20-B07	SBT20-B07	SBT20-B07
* 8	背托環	1	SBT20-B06	SBT20-B06	SBT20-B06	SBT20-B06	SBT20-B06	SBT20-B06	SBT20-B06
* 9	O型環	1	XBAS227-90	XBAS227-90	XBAS227-90	XBAS227-90	XBAS227-90	XBAS227-90	XBAS227-90
* 10	O型環	1	XBAS231-90	XBAS231-90	XBAS231-90	XBAS231-90	XBAS231-90	XBAS231-90	XBAS231-90
11	接頭	2	SBTN-G1412G1412E	SBTN-G1412G1412E	SBTN-G1412G1412E	SBTN-G1412G1412E	SBTN-G1412G1412E	SBTN-G1412G1412E	SBTN-G1412G1412E
12	快速接頭公	1	SBT-CE116-M	SBT-CE116-M	SBT-CE116-M	SBT-CE116-M	SBT-CE116-M	SBT-CE116-M	SBT-CE116-M
14	扳桿	1	XJSBT-10	XJSBT-10	XJSBT-10	XJSBT-10	XJSBT-10	XJSBT-10	XJSBT-10
15	快速接頭母	1	SBT-CE116-F	SBT-CE116-F	SBT-CE116-F	SBT-CE116-F	SBT-CE116-F	SBT-CE116-F	SBT-CE116-F

*修理包




編號	品名	1"		1-1/8"		1-1/4"		1-3/8"		M27		M30		M33		M36	
		數量	品號	數量	品號	數量	品號	數量	品號	數量	品號	數量	品號	數量	品號	數量	品號
1	油壓缸	1	SBT35-B01	1	SBT35-B01	1	SBT35-B01	1	SBT35-B01	1	SBT35-B01	1	SBT35-B01	1	SBT35-B01	1	SBT35-B01
2	主軸	1	SBT35-B02	1	SBT35-B02	1	SBT35-B02	1	SBT35-B02	1	SBT35-B02	1	SBT35-B02	1	SBT35-B02	1	SBT35-B02
3	螺牙帽	1	SBT-35T 1"	1	SBT-35T 1_1/8"	1	SBT-35T 1_1/4"	1	SBT-35T 1_3/8"	1	SBT-35T M27	1	SBT-35T M30	1	SBT-35T M33	1	SBT-35T M36
4	架橋	1	SBT-35J	1	SBT-35J	1	SBT-35J	1	SBT-35J	1	SBT-35J	1	SBT-35J	1	SBT-35J	1	SBT-35J
5	六角套筒	1	SBT-35H 41	1	SBT-35H 46	1	SBT-35H 50	1	SBT-35H 55	1	SBT-35H 41	1	SBT-35H 46	1	SBT-35H 50	1	SBT-35H 55
6	螺栓	3	XNSETM06-12-N	3	XNSETM06-12-N	3	XNSETM06-12-N	3	XNSETM06-12-N	3	XNSETM06-12-N	3	XNSETM06-12-N	3	XNSETM06-12-N	3	XNSETM06-12-N
* 7	背托環	1	SBT35-B07	1	SBT35-B07	1	SBT35-B07	1	SBT35-B07	1	SBT35-B07	1	SBT35-B07	1	SBT35-B07	1	SBT35-B07
* 8	背托環	1	SBT35-B06	1	SBT35-B06	1	SBT35-B06	1	SBT35-B06	1	SBT35-B06	1	SBT35-B06	1	SBT35-B06	1	SBT35-B06
* 9	O型環	1	XBP067-90-NOK	1	XBP067-90-NOK	1	XBP067-90-NOK	1	XBP067-90-NOK	1	XBP067-90-NOK	1	XBP067-90-NOK	1	XBP067-90-NOK	1	XBP067-90-NOK
* 10	O型環	1	XBP085-90-NOK	1	XBP085-90-NOK	1	XBP085-90-NOK	1	XBP085-90-NOK	1	XBP085-90-NOK	1	XBP085-90-NOK	1	XBP085-90-NOK	1	XBP085-90-NOK
11	接頭	2	SBTN-G1412G1412E	2	SBTN-G1412G1412E	2	SBTN-G1412G1412E	2	SBTN-G1412G1412E	2	SBTN-G1412G1412E	2	SBTN-G1412G1412E	2	SBTN-G1412G1412E	2	SBTN-G1412G1412E
12	快速接頭公	1	SBT-CE116-M	1	SBT-CE116-M	1	SBT-CE116-M	1	SBT-CE116-M	1	SBT-CE116-M	1	SBT-CE116-M	1	SBT-CE116-M	1	SBT-CE116-M
14	扳桿	1	XJSBT-10	1	XJSBT-10	1	XJSBT-10	1	XJSBT-10	1	XJSBT-10	1	XJSBT-10	1	XJSBT-10	1	XJSBT-10
15	快速接頭母	1	SBT-CE116-F	1	SBT-CE116-F	1	SBT-CE116-F	1	SBT-CE116-F	1	SBT-CE116-F	1	SBT-CE116-F	1	SBT-CE116-F	1	SBT-CE116-F

*修理包




編號	品名	數量	1-3/8"	1-1/2"	1-3/4"	M36	M39	M42	M45
			品號	品號	品號	品號	品號	品號	品號
1	油壓缸	1	SBT50-B01	SBT50-B01	SBT50-B01	SBT50-B01	SBT50-B01	SBT50-B01	SBT50-B01
2	主軸	1	SBT50-B02	SBT50-B02	SBT50-B02	SBT50-B02	SBT50-B02	SBT50-B02	SBT50-B02
3	螺牙帽	1	SBT-50T 1_3/8"	SBT-50T 1_1/2"	SBT-50T 1_3/4"	SBT-50T M36	SBT-50T M39	SBT-50T M42	SBT-50T M45
4	架橋	1	SBT50-J	SBT50-J	SBT50-J	SBT50-J	SBT50-J	SBT50-J	SBT50-J
5	六角套筒	1	SBT-50H 55	SBT-50H 60	SBT-50H 70	SBT-50H 55	SBT-50H 60	SBT-50H 65	SBT-50H 70
6	螺栓	3	XNSETM06-12-N	XNSETM06-12-N	XNSETM06-12-N	XNSETM06-12-N	XNSETM06-12-N	XNSETM06-12-N	XNSETM06-12-N
* 7	背托環	1	SBT50-B07	SBT50-B07	SBT50-B07	SBT50-B07	SBT50-B07	SBT50-B07	SBT50-B07
* 8	背托環	1	SBT50-B06	SBT50-B06	SBT50-B06	SBT50-B06	SBT50-B06	SBT50-B06	SBT50-B06
* 9	O型環	1	XBP75-90-NOK	XBP75-90-NOK	XBP75-90-NOK	XBP75-90-NOK	XBP75-90-NOK	XBP75-90-NOK	XBP75-90-NOK
* 10	O型環	1	XBP100-90-NOK	XBP100-90-NOK	XBP100-90-NOK	XBP100-90-NOK	XBP100-90-NOK	XBP100-90-NOK	XBP100-90-NOK
* 11	接頭	2	SBTN-G1412G1412E	SBTN-G1412G1412E	SBTN-G1412G1412E	SBTN-G1412G1412E	SBTN-G1412G1412E	SBTN-G1412G1412E	SBTN-G1412G1412E
12	快速接頭公	1	SBT-CE116-M	SBT-CE116-M	SBT-CE116-M	SBT-CE116-M	SBT-CE116-M	SBT-CE116-M	SBT-CE116-M
13	止動環	1	SBT50-B08	SBT50-B08	SBT50-B08	SBT50-B08	SBT50-B08	SBT50-B08	SBT50-B08
14	扳桿	1	XJ10-150	XJ10-150	XJ10-150	XJ10-150	XJ10-150	XJ10-150	XJ10-150
15	快速接頭母	1	SBT-CE116-F	SBT-CE116-F	SBT-CE116-F	SBT-CE116-F	SBT-CE116-F	SBT-CE116-F	SBT-CE116-F

*修理包




編號	品名	數量	1-1/2"	1-3/4"	2"	M42	M45	M48	M52
			品號	品號	品號	品號	品號	品號	品號
1	油壓缸	1	SBT60-B01	SBT60-B01	SBT60-B01	SBT60-B01	SBT60-B01	SBT60-B01	SBT60-B01
2	主軸	1	SBT60-B02	SBT60-B02	SBT60-B02	SBT60-B02	SBT60-B02	SBT60-B02	SBT60-B02
3	螺牙帽	1	SBT-60T 1_1/2"	SBT-60T 1_3/4"	SBT-60T 2"	SBT-60T M42	SBT-60T M45	SBT-60T M48	SBT-60T M52
4	架橋	1	SBT-60J	SBT-60J	SBT-60J	SBT-60J	SBT-60J	SBT-60J	SBT-60J
5	六角套筒	1	SBT-60H 60	SBT-60H 70	SBT-60H 80	SBT-60H 65	SBT-60H 70	SBT-60H 75	SBT-60H 80
6	螺栓	3	XNSETM06-12-N	XNSETM06-12-N	XNSETM06-12-N	XNSETM06-12-N	XNSETM06-12-N	XNSETM06-12-N	XNSETM06-12-N
* 7	背托環	1	SBT60-B07	SBT60-B07	SBT60-B07	SBT60-B07	SBT60-B07	SBT60-B07	SBT60-B07
* 8	背托環	1	SBT60-B06	SBT60-B06	SBT60-B06	SBT60-B06	SBT60-B06	SBT60-B06	SBT60-B06
* 9	O型環	1	XBP080-90-NOK	XBP080-90-NOK	XBP080-90-NOK	XBP080-90-NOK	XBP080-90-NOK	XBP080-90-NOK	XBP080-90-NOK
* 10	O型環	1	XBP110-90-NOK	XBP110-90-NOK	XBP110-90-NOK	XBP110-90-NOK	XBP110-90-NOK	XBP110-90-NOK	XBP110-90-NOK
* 11	接頭	2	SBTN-G1412G1412E	SBTN-G1412G1412E	SBTN-G1412G1412E	SBTN-G1412G1412E	SBTN-G1412G1412E	SBTN-G1412G1412E	SBTN-G1412G1412E
12	快速接頭公	1	SBT-CE116-M	SBT-CE116-M	SBT-CE116-M	SBT-CE116-M	SBT-CE116-M	SBT-CE116-M	SBT-CE116-M
13	止動環	1	SBT60-B08	SBT60-B08	SBT60-B08	SBT60-B08	SBT60-B08	SBT60-B08	SBT60-B08
14	扳桿	1	XJSBT-12	XJSBT-12	XJSBT-12	XJSBT-12	XJSBT-12	XJSBT-12	XJSBT-12
15	快速接頭母	1	SBT-CE116-F	SBT-CE116-F	SBT-CE116-F	SBT-CE116-F	SBT-CE116-F	SBT-CE116-F	SBT-CE116-F

*修理包




編號	品名	數量	1-3/4"	2"	2-1/4"	M45	M48	M52	M56	M60
			品號	品號	品號	品號	品號	品號	品號	品號
1	油壓缸	1	SBT90-B01	SBT90-B01	SBT90-B01	SBT90-B01	SBT90-B01	SBT90-B01	SBT90-B01	SBT90-B01
2	主軸	1	SBT90-B02	SBT90-B02	SBT90-B02	SBT90-B02	SBT90-B02	SBT90-B02	SBT90-B02	SBT90-B02
3	螺牙帽	1	SBT-90T 1_3/4"	SBT-90T 2"	SBT-90T 2_1/4"	SBT-90T M45	SBT-90T M48	SBT-90T M52	SBT-90T M56	SBT-90T M60
4	架橋	1	SBT-90J	SBT-90J	SBT-90J	SBT-90J	SBT-90J	SBT-90J	SBT-90J	SBT-90J
5	六角套筒	1	SBT-90H 70	SBT-90H 80	SBT-90H 90	SBT-90H 70	SBT-90H 75	SBT-90H 80	SBT-90H 85	SBT-90H 90
6	螺栓	3	XNSETM06-12-N	XNSETM06-12-N	XNSETM06-12-N	XNSETM06-12-N	XNSETM06-12-N	XNSETM06-12-N	XNSETM06-12-N	XNSETM06-12-N
* 7	背托環	1	SBT90-B07	SBT90-B07	SBT90-B07	SBT90-B07	SBT90-B07	SBT90-B07	SBT90-B07	SBT90-B07
* 8	背托環	1	SBT90-B06	SBT90-B06	SBT90-B06	SBT90-B06	SBT90-B06	SBT90-B06	SBT90-B06	SBT90-B06
* 9	O型環	1	XBP100-90-NOK	XBP100-90-NOK	XBP100-90-NOK	XBP100-90-NOK	XBP100-90-NOK	XBP100-90-NOK	XBP100-90-NOK	XBP100-90-NOK
* 10	O型環	1	XBP135-90-NOK	XBP135-90-NOK	XBP135-90-NOK	XBP135-90-NOK	XBP135-90-NOK	XBP135-90-NOK	XBP135-90-NOK	XBP135-90-NOK
11	接頭	2	SBTN-G1412G1412E	SBTN-G1412G1412E	SBTN-G1412G1412E	SBTN-G1412G1412E	SBTN-G1412G1412E	SBTN-G1412G1412E	SBTN-G1412G1412E	SBTN-G1412G1412E
12	快速接頭公	1	SBT-CE116-M	SBT-CE116-M	SBT-CE116-M	SBT-CE116-M	SBT-CE116-M	SBT-CE116-M	SBT-CE116-M	SBT-CE116-M
13	止動環	1	SBT90-B08	SBT90-B08	SBT90-B08	SBT90-B08	SBT90-B08	SBT90-B08	SBT90-B08	SBT90-B08
14	扳桿	1	XJSBT-12	XJSBT-12	XJSBT-12	XJSBT-12	XJSBT-12	XJSBT-12	XJSBT-12	XJSBT-12
15	快速接頭公	1	SBT-CE116-F	SBT-CE116-F	SBT-CE116-F	SBT-CE116-F	SBT-CE116-F	SBT-CE116-F	SBT-CE116-F	SBT-CE116-F

*修理包




編號	品名	數量	2-1/2"	2-3/4"	M60	M64	M68	M72	M76
			品號	品號	品號	品號	品號	品號	品號
1	油壓缸	1	SBT130-B01	SBT130-B01	SBT130-B01	SBT130-B01	SBT130-B01	SBT130-B01	SBT130-B01
2	主軸	1	SBT130-B02	SBT130-B02	SBT130-B02	SBT130-B02	SBT130-B02	SBT130-B02	SBT130-B02
3	螺牙帽	1	SBT-130T 2_1/2"	SBT-130T 2_3/4"	SBT-130T M60	SBT-130T M64	SBT-130T M68	SBT-130T M72	SBT-130T M76
4	架橋	1	SBT-130J	SBT-130J	SBT-130J	SBT-130J	SBT-130J	SBT-130J	SBT-130J
5	六角套筒	1	SBT-130H 100	SBT-130H 108	SBT-130H 90	SBT-130H 95	SBT-130H 100	SBT-130H 105	SBT-130H 110
6	螺栓	3	XNSETM06-12-N	XNSETM06-12-N	XNSETM06-12-N	XNSETM06-12-N	XNSETM06-12-N	XNSETM06-12-N	XNSETM06-12-N
* 7	背托環	1	SBT130-B07	SBT130-B07	SBT130-B07	SBT130-B07	SBT130-B07	SBT130-B07	SBT130-B07
* 8	背托環	1	SBT130-B06	SBT130-B06	SBT130-B06	SBT130-B06	SBT130-B06	SBT130-B06	SBT130-B06
* 9	O型環	1	XBP110-90-NOK	XBP110-90-NOK	XBP110-90-NOK	XBP110-90-NOK	XBP110-90-NOK	XBP110-90-NOK	XBP110-90-NOK
* 10	O型環	1	XBP160-90-NOK	XBP160-90-NOK	XBP160-90-NOK	XBP160-90-NOK	XBP160-90-NOK	XBP160-90-NOK	XBP160-90-NOK
11	接頭	2	SBTN-G1412G1412E	SBTN-G1412G1412E	SBTN-G1412G1412E	SBTN-G1412G1412E	SBTN-G1412G1412E	SBTN-G1412G1412E	SBTN-G1412G1412E
12	快速接頭公	1	SBT-CE116-M	SBT-CE116-M	SBT-CE116-M	SBT-CE116-M	SBT-CE116-M	SBT-CE116-M	SBT-CE116-M
13	止動環	1	SBT130-B08	SBT130-B08	SBT130-B08	SBT130-B08	SBT130-B08	SBT130-B08	SBT130-B08
14	扳桿	1	XJSBT-16	XJSBT-16	XJSBT-16	XJSBT-16	XJSBT-16	XJSBT-16	XJSBT-16
15	快速接頭母	1	SBT-CE116-F	SBT-CE116-F	SBT-CE116-F	SBT-CE116-F	SBT-CE116-F	SBT-CE116-F	SBT-CE116-F

*修理包




編號	品名	數量	2-3/4"	3"	M72	M76	M80
			品號	品號	品號	品號	品號
1	油壓缸	1	SBT160-B01	SBT160-B01	SBT160-B01	SBT160-B01	SBT160-B01
2	主軸	1	SBT160-B02	SBT160-B02	SBT160-B02	SBT160-B02	SBT160-B02
3	螺牙帽	1	SBT-160T 2.3/4"	SBT-160T 3"	SBT-160T M72	SBT-160T M76	SBT-160T M80
4	架橋	1	SBT-160J	SBT-160J	SBT-160J	SBT-160J	SBT-160J
5	六角套筒	1	SBT-160H 108	SBT-160H 118	SBT-160H 105	SBT-160H 110	SBT-160H 115
6	螺栓	3	XNSETM06-12-N	XNSETM06-12-N	XNSETM06-12-N	XNSETM06-12-N	XNSETM06-12-N
* 7	背托環	1	SBT160-B07	SBT160-B07	SBT160-B07	SBT160-B07	SBT160-B07
* 8	背托環	1	SBT160-B06	SBT160-B06	SBT160-B06	SBT160-B06	SBT160-B06
* 9	O型環	1	XBP125-90-NOK	XBP125-90-NOK	XBP125-90-NOK	XBP125-90-NOK	XBP125-90-NOK
* 10	O型環	1	XBP180-90-NOK	XBP180-90-NOK	XBP180-90-NOK	XBP180-90-NOK	XBP180-90-NOK
11	接頭	2	SBTN-G1412G1412E	SBTN-G1412G1412E	SBTN-G1412G1412E	SBTN-G1412G1412E	SBTN-G1412G1412E
12	快速接頭公	1	SBT-CE116-M	SBT-CE116-M	SBT-CE116-M	SBT-CE116-M	SBT-CE116-M
13	止動環	1	SBT160-B08	SBT160-B08	SBT160-B08	SBT160-B08	SBT160-B08
14	扳桿	1	XJSBT-16	XJSBT-16	XJSBT-16	XJSBT-16	XJSBT-16
15	快速接頭母	1	SBT-CE116-F	SBT-CE116-F	SBT-CE116-F	SBT-CE116-F	SBT-CE116-F

*修理包




編號	品名	數量	3-1/4"	3-1/2"	3-3/4"	M80	M85	M90	M95	M100
			品號	品號	品號	品號	品號	品號	品號	品號
1	油壓缸	1	SBT200-B01	SBT200-B01	SBT200-B01	SBT200-B01	SBT200-B01	SBT200-B01	SBT200-B01	SBT200-B01
2	主軸	1	SBT200-B02	SBT200-B02	SBT200-B02	SBT200-B02	SBT200-B02	SBT200-B02	SBT200-B02	SBT200-B02
3	螺牙帽	1	SBT-200T 3.1/4"	SBT-200T 3.1/2"	SBT-200T 3.3/4"	SBT-200T M80	SBT-200T M85	SBT-200T M85	SBT-200T M95	SBT-200T M100
4	架橋	1	SBT-200J	SBT-200J	SBT-200J	SBT-200J	SBT-200J	SBT-200J	SBT-200J	SBT-200J
5	六角套筒	1	SBT-200H 127	SBT-200H 137	SBT-200H 146	SBT-200H 115	SBT-200H 120	SBT-200H 130	SBT-200H 135	SBT-200H 145
6	螺栓	3	XNSETM06-12-N	XNSETM06-12-N	XNSETM06-12-N	XNSETM06-12-N	XNSETM06-12-N	XNSETM06-12-N	XNSETM06-12-N	XNSETM06-12-N
* 7	背托環	1	SBT200-B07	SBT200-B07	SBT200-B07	SBT200-B07	SBT200-B07	SBT200-B07	SBT200-B07	SBT200-B07
* 8	背托環	1	SBT200-B06	SBT200-B06	SBT200-B06	SBT200-B06	SBT200-B06	SBT200-B06	SBT200-B06	SBT200-B06
* 9	O型環	1	XBP135-90-NOK	XBP135-90-NOK	XBP135-90-NOK	XBP135-90-NOK	XBP135-90-NOK	XBP135-90-NOK	XBP135-90-NOK	XBP135-90-NOK
* 10	O型環	1	XBP200-90-NOK	XBP200-90-NOK	XBP200-90-NOK	XBP200-90-NOK	XBP200-90-NOK	XBP200-90-NOK	XBP200-90-NOK	XBP200-90-NOK
11	接頭	2	SBTN-G1412G1412E	SBTN-G1412G1412E	SBTN-G1412G1412E	SBTN-G1412G1412E	SBTN-G1412G1412E	SBTN-G1412G1412E	SBTN-G1412G1412E	SBTN-G1412G1412E
12	快速接頭公	1	SBT-CE116-M	SBT-CE116-M	SBT-CE116-M	SBT-CE116-M	SBT-CE116-M	SBT-CE116-M	SBT-CE116-M	SBT-CE116-M
13	止動環	1	SBT200-B08	SBT200-B08	SBT200-B08	SBT200-B08	SBT200-B08	SBT200-B08	SBT200-B08	SBT200-B08
14	扳桿	1	XJSBT-16	XJSBT-16	XJSBT-16	XJSBT-16	XJSBT-16	XJSBT-16	XJSBT-16	XJSBT-16
15	快速接頭母	1	SBT-CE116-F	SBT-CE116-F	SBT-CE116-F	SBT-CE116-F	SBT-CE116-F	SBT-CE116-F	SBT-CE116-F	SBT-CE116-F

*修理包




Item	Product	Q'ty	3/4"	7/8"	1"	M20	M22	M24	M27
			Part Number	Part Number	Part Number	Part Number	Part Number	Part Number	Part Number
1	Cylinder	1	SBT20-B01	SBT20-B01	SBT20-B01	SBT20-B01	SBT20-B01	SBT20-B01	SBT20-B01
2	Plunger	1	SBT20-B02	SBT20-B02	SBT20-B02	SBT20-B02	SBT20-B02	SBT20-B02	SBT20-B02
3	Thread adaptor	1	SBT-20T 3/4"	SBT-20T 7/8"	SBT-20T 1"	SBT-20T M20	SBT-20T M22	SBT-20T M24	SBT-20T M27
4	Bridge	1	SBT-20J	SBT-20J	SBT-20J	SBT-20J	SBT-20J	SBT-20J	SBT-20J
5	Hex Socket	1	SBT-20H 32	SBT-20H 36	SBT-20H 41	SBT-20H 30	SBT-20H 32	SBT-20H 36	SBT-20H 41
6	bolt	3	XNSETM06-12-N	XNSETM06-12-N	XNSETM06-12-N	XNSETM06-12-N	XNSETM06-12-N	XNSETM06-12-N	XNSETM06-12-N
* 7	back-up ring	1	SBT20-B07	SBT20-B07	SBT20-B07	SBT20-B07	SBT20-B07	SBT20-B07	SBT20-B07
* 8	back-up ring	1	SBT20-B06	SBT20-B06	SBT20-B06	SBT20-B06	SBT20-B06	SBT20-B06	SBT20-B06
* 9	O ring	1	XBAS227-90	XBAS227-90	XBAS227-90	XBAS227-90	XBAS227-90	XBAS227-90	XBAS227-90
* 10	O ring	1	XBAS231-90	XBAS231-90	XBAS231-90	XBAS231-90	XBAS231-90	XBAS231-90	XBAS231-90
11	nipple	2	SBTN-G1412G1412E	SBTN-G1412G1412E	SBTN-G1412G1412E	SBTN-G1412G1412E	SBTN-G1412G1412E	SBTN-G1412G1412E	SBTN-G1412G1412E
12	Coupler-male	1	SBT-CE116-M	SBT-CE116-M	SBT-CE116-M	SBT-CE116-M	SBT-CE116-M	SBT-CE116-M	SBT-CE116-M
14	nut-turning bar	1	XJSBT-10	XJSBT-10	XJSBT-10	XJSBT-10	XJSBT-10	XJSBT-10	XJSBT-10
15	Coupler-female	1	SBT-CE116-F	SBT-CE116-F	SBT-CE116-F	SBT-CE116-F	SBT-CE116-F	SBT-CE116-F	SBT-CE116-F

Maked with * are contained in Repair Kit.




Item	Product	Q'ty	Part Number	1-1/8"	1-1/4"	1-3/8"	M27	M30	M33	M36
1	Cylinder	1	SBT35-B01	SBT35-B01	SBT35-B01	SBT35-B01	SBT35-B01	SBT35-B01	SBT35-B01	SBT35-B01
2	Plunger	1	SBT35-B02	SBT35-B02	SBT35-B02	SBT35-B02	SBT35-B02	SBT35-B02	SBT35-B02	SBT35-B02
3	Thread adaptor	1	SBT-35T 1"	SBT-35T 1 1/8"	SBT-35T 1 1/4"	SBT-35T 1 3/8"	SBT-35T M27	SBT-35T M30	SBT-35T M33	SBT-35T M36
4	Bridge	1	SBT-35J	SBT-35J	SBT-35J	SBT-35J	SBT-35J	SBT-35J	SBT-35J	SBT-35J
5	Hex Socket	1	SBT-35H 41	SBT-35H 46	SBT-35H 50	SBT-35H 55	SBT-35H 41	SBT-35H 46	SBT-35H 50	SBT-35H 55
6	bolt	3	XNSETM06-12-N	XNSETM06-12-N	XNSETM06-12-N	XNSETM06-12-N	XNSETM06-12-N	XNSETM06-12-N	XNSETM06-12-N	XNSETM06-12-N
* 7	back-up ring	1	SBT35-B07	SBT35-B07	SBT35-B07	SBT35-B07	SBT35-B07	SBT35-B07	SBT35-B07	SBT35-B07
* 8	back-up ring	1	SBT35-B06	SBT35-B06	SBT35-B06	SBT35-B06	SBT35-B06	SBT35-B06	SBT35-B06	SBT35-B06
* 9	O ring	1	XBP067-90-NOK	XBP067-90-NOK	XBP067-90-NOK	XBP067-90-NOK	XBP067-90-NOK	XBP067-90-NOK	XBP067-90-NOK	XBP067-90-NOK
* 10	O ring	1	XBP085-90-NOK	XBP085-90-NOK	XBP085-90-NOK	XBP085-90-NOK	XBP085-90-NOK	XBP085-90-NOK	XBP085-90-NOK	XBP085-90-NOK
11	nipple	2	SBTN-G1412G1412E	SBTN-G1412G1412E	SBTN-G1412G1412E	SBTN-G1412G1412E	SBTN-G1412G1412E	SBTN-G1412G1412E	SBTN-G1412G1412E	SBTN-G1412G1412E
12	Coupler-male	1	SBT-CE116-M	SBT-CE116-M	SBT-CE116-M	SBT-CE116-M	SBT-CE116-M	SBT-CE116-M	SBT-CE116-M	SBT-CE116-M
14	nut-turning bar	1	XJSBT-10	XJSBT-10	XJSBT-10	XJSBT-10	XJSBT-10	XJSBT-10	XJSBT-10	XJSBT-10
15	Coupler-female	1	SBT-CE116-F	SBT-CE116-F	SBT-CE116-F	SBT-CE116-F	SBT-CE116-F	SBT-CE116-F	SBT-CE116-F	SBT-CE116-F

Maked with * are contained in Repair Kit.




Item	Product	Q'ty	1-3/8"	1-1/2"	1-3/4"	M36	M39	M42	M45
			Part Number	Part Number	Part Number	Part Number	Part Number	Part Number	Part Number
1	Cylinder	1	SBT50-B01	SBT50-B01	SBT50-B01	SBT50-B01	SBT50-B01	SBT50-B01	SBT50-B01
2	Plunger	1	SBT50-B02	SBT50-B02	SBT50-B02	SBT50-B02	SBT50-B02	SBT50-B02	SBT50-B02
3	Thread adaptor	1	SBT-50T 1 3/8"	SBT-50T 1 1/2"	SBT-50T 1 3/4"	SBT-50T M36	SBT-50T M39	SBT-50T M42	SBT-50T M45
4	Bridge	1	SBT50-J	SBT50-J	SBT50-J	SBT50-J	SBT50-J	SBT50-J	SBT50-J
5	Hex Socket	1	SBT-50H 55	SBT-50H 60	SBT-50H 70	SBT-50H 55	SBT-50H 60	SBT-50H 65	SBT-50H 70
6	bolt	3	XNSETM06-12-N	XNSETM06-12-N	XNSETM06-12-N	XNSETM06-12-N	XNSETM06-12-N	XNSETM06-12-N	XNSETM06-12-N
* 7	back-up ring	1	SBT50-B07	SBT50-B07	SBT50-B07	SBT50-B07	SBT50-B07	SBT50-B07	SBT50-B07
* 8	back-up ring	1	SBT50-B06	SBT50-B06	SBT50-B06	SBT50-B06	SBT50-B06	SBT50-B06	SBT50-B06
* 9	O ring	1	XBP75-90-NOK	XBP75-90-NOK	XBP75-90-NOK	XBP75-90-NOK	XBP75-90-NOK	XBP75-90-NOK	XBP75-90-NOK
* 10	O ring	1	XBP100-90-NOK	XBP100-90-NOK	XBP100-90-NOK	XBP100-90-NOK	XBP100-90-NOK	XBP100-90-NOK	XBP100-90-NOK
* 11	nipple	2	SBTN-G1412G1412E	SBTN-G1412G1412E	SBTN-G1412G1412E	SBTN-G1412G1412E	SBTN-G1412G1412E	SBTN-G1412G1412E	SBTN-G1412G1412E
12	Coupler-male	1	SBT-CE116-M	SBT-CE116-M	SBT-CE116-M	SBT-CE116-M	SBT-CE116-M	SBT-CE116-M	SBT-CE116-M
13	stop ring	1	SBT50-B08	SBT50-B08	SBT50-B08	SBT50-B08	SBT50-B08	SBT50-B08	SBT50-B08
14	nut-turning bar	1	XJ10-150	XJ10-150	XJ10-150	XJ10-150	XJ10-150	XJ10-150	XJ10-150
15	Coupler-female	1	SBT-CE116-F	SBT-CE116-F	SBT-CE116-F	SBT-CE116-F	SBT-CE116-F	SBT-CE116-F	SBT-CE116-F

Maked with * are contained in Repair Kit.




Item	Product	Qty	1-1/2"		1-3/4"		2"		M42		M45		M48		M52	
			Part Number	Part Number	Part Number	Part Number	Part Number	Part Number	Part Number	Part Number	Part Number	Part Number	Part Number			
1	Cylinder	1	SBT60-B01	SBT60-B01	SBT60-B01	SBT60-B01	SBT60-B01	SBT60-B01	SBT60-B01	SBT60-B01	SBT60-B01	SBT60-B01	SBT60-B01	SBT60-B01	SBT60-B01	SBT60-B01
2	Plunger	1	SBT60-B02	SBT60-B02	SBT60-B02	SBT60-B02	SBT60-B02	SBT60-B02	SBT60-B02	SBT60-B02	SBT60-B02	SBT60-B02	SBT60-B02	SBT60-B02	SBT60-B02	SBT60-B02
3	Thread adaptor	1	SBT-60T 1_1/2"	SBT-60T 1_3/4"	SBT-60T 2"	SBT-60T M42	SBT-60T M45	SBT-60T M48	SBT-60T M52							
4	Bridge	1	SBT-60J	SBT-60J	SBT-60J	SBT-60J	SBT-60J	SBT-60J	SBT-60J	SBT-60J	SBT-60J	SBT-60J	SBT-60J	SBT-60J	SBT-60J	SBT-60J
5	Hex Socket	1	SBT-60H 60	SBT-60H 70	SBT-60H 80	SBT-60H 65	SBT-60H 70	SBT-60H 75	SBT-60H 80							
6	bolt	3	XNSETM06-12-N	XNSETM06-12-N	XNSETM06-12-N	XNSETM06-12-N	XNSETM06-12-N	XNSETM06-12-N	XNSETM06-12-N	XNSETM06-12-N	XNSETM06-12-N	XNSETM06-12-N	XNSETM06-12-N	XNSETM06-12-N	XNSETM06-12-N	XNSETM06-12-N
* 7	back-up ring	1	SBT60-B07	SBT60-B07	SBT60-B07	SBT60-B07	SBT60-B07	SBT60-B07	SBT60-B07	SBT60-B07	SBT60-B07	SBT60-B07	SBT60-B07	SBT60-B07	SBT60-B07	SBT60-B07
* 8	back-up ring	1	SBT60-B06	SBT60-B06	SBT60-B06	SBT60-B06	SBT60-B06	SBT60-B06	SBT60-B06	SBT60-B06	SBT60-B06	SBT60-B06	SBT60-B06	SBT60-B06	SBT60-B06	SBT60-B06
* 9	O ring	1	XBP080-90-NOK	XBP080-90-NOK	XBP080-90-NOK	XBP080-90-NOK	XBP080-90-NOK	XBP080-90-NOK	XBP080-90-NOK	XBP080-90-NOK	XBP080-90-NOK	XBP080-90-NOK	XBP080-90-NOK	XBP080-90-NOK	XBP080-90-NOK	XBP080-90-NOK
* 10	O ring	1	XBP110-90-NOK	XBP110-90-NOK	XBP110-90-NOK	XBP110-90-NOK	XBP110-90-NOK	XBP110-90-NOK	XBP110-90-NOK	XBP110-90-NOK	XBP110-90-NOK	XBP110-90-NOK	XBP110-90-NOK	XBP110-90-NOK	XBP110-90-NOK	XBP110-90-NOK
11	nipple	2	SBTN-G1412G1412E	SBTN-G1412G1412E	SBTN-G1412G1412E	SBTN-G1412G1412E	SBTN-G1412G1412E	SBTN-G1412G1412E	SBTN-G1412G1412E	SBTN-G1412G1412E	SBTN-G1412G1412E	SBTN-G1412G1412E	SBTN-G1412G1412E	SBTN-G1412G1412E	SBTN-G1412G1412E	SBTN-G1412G1412E
12	Coupler-male	1	SBT-CE116-M	SBT-CE116-M	SBT-CE116-M	SBT-CE116-M	SBT-CE116-M	SBT-CE116-M	SBT-CE116-M	SBT-CE116-M	SBT-CE116-M	SBT-CE116-M	SBT-CE116-M	SBT-CE116-M	SBT-CE116-M	SBT-CE116-M
13	stop ring	1	SBT60-B08	SBT60-B08	SBT60-B08	SBT60-B08	SBT60-B08	SBT60-B08	SBT60-B08	SBT60-B08	SBT60-B08	SBT60-B08	SBT60-B08	SBT60-B08	SBT60-B08	SBT60-B08
14	nut-turning bar	1	XJSBT-12	XJSBT-12	XJSBT-12	XJSBT-12	XJSBT-12	XJSBT-12	XJSBT-12	XJSBT-12	XJSBT-12	XJSBT-12	XJSBT-12	XJSBT-12	XJSBT-12	XJSBT-12
15	Coupler-female	1	SBT-CE116-F	SBT-CE116-F	SBT-CE116-F	SBT-CE116-F	SBT-CE116-F	SBT-CE116-F	SBT-CE116-F	SBT-CE116-F	SBT-CE116-F	SBT-CE116-F	SBT-CE116-F	SBT-CE116-F	SBT-CE116-F	SBT-CE116-F

Maked with * are contained in Repair Kit.




Item	Product	Q'ty	1-3/4"	2"	2-1/4"	M45	M48	M52	M56	M60
			Part Number	Part Number	Part Number	Part Number	Part Number	Part Number	Part Number	Part Number
1	Cylinder	1	SBT90-B01	SBT90-B01	SBT90-B01	SBT90-B01	SBT90-B01	SBT90-B01	SBT90-B01	SBT90-B01
2	Plunger	1	SBT90-B02	SBT90-B02	SBT90-B02	SBT90-B02	SBT90-B02	SBT90-B02	SBT90-B02	SBT90-B02
3	Thread adaptor	1	SBT-90T 1 3/4"	SBT-90T 2"	SBT-90T 2 1/4"	SBT-90T M45	SBT-90T M48	SBT-90T M52	SBT-90T M56	SBT-90T M60
4	Bridge	1	SBT-90J	SBT-90J	SBT-90J	SBT-90J	SBT-90J	SBT-90J	SBT-90J	SBT-90J
5	Hex Socket	1	SBT-90H 70	SBT-90H 80	SBT-90H 90	SBT-90H 70	SBT-90H 75	SBT-90H 80	SBT-90H 85	SBT-90H 90
6	bolt	3	XNSETM06-12-N	XNSETM06-12-N	XNSETM06-12-N	XNSETM06-12-N	XNSETM06-12-N	XNSETM06-12-N	XNSETM06-12-N	XNSETM06-12-N
* 7	back-up ring	1	SBT90-B07	SBT90-B07	SBT90-B07	SBT90-B07	SBT90-B07	SBT90-B07	SBT90-B07	SBT90-B07
* 8	back-up ring	1	SBT90-B06	SBT90-B06	SBT90-B06	SBT90-B06	SBT90-B06	SBT90-B06	SBT90-B06	SBT90-B06
* 9	O ring	1	XBP100-90-NOK	XBP100-90-NOK	XBP100-90-NOK	XBP100-90-NOK	XBP100-90-NOK	XBP100-90-NOK	XBP100-90-NOK	XBP100-90-NOK
* 10	O ring	1	XBP135-90-NOK	XBP135-90-NOK	XBP135-90-NOK	XBP135-90-NOK	XBP135-90-NOK	XBP135-90-NOK	XBP135-90-NOK	XBP135-90-NOK
11	nipple	2	SBTN-G1412G1412E	SBTN-G1412G1412E	SBTN-G1412G1412E	SBTN-G1412G1412E	SBTN-G1412G1412E	SBTN-G1412G1412E	SBTN-G1412G1412E	SBTN-G1412G1412E
12	Coupler-male	1	SBT-CE116-M	SBT-CE116-M	SBT-CE116-M	SBT-CE116-M	SBT-CE116-M	SBT-CE116-M	SBT-CE116-M	SBT-CE116-M
13	stop ring	1	SBT90-B08	SBT90-B08	SBT90-B08	SBT90-B08	SBT90-B08	SBT90-B08	SBT90-B08	SBT90-B08
14	nut-turning bar	1	XJSBT-12	XJSBT-12	XJSBT-12	XJSBT-12	XJSBT-12	XJSBT-12	XJSBT-12	XJSBT-12
15	Coupler-female	1	SBT-CE116-F	SBT-CE116-F	SBT-CE116-F	SBT-CE116-F	SBT-CE116-F	SBT-CE116-F	SBT-CE116-F	SBT-CE116-F

Maked with * are contained in Repair Kit.




Item	Product	Q'ty	2-1/2"	2-3/4"	M60	M64	M68	M72	M76
			Part Number	Part Number	Part Number	Part Number	Part Number	Part Number	Part Number
1	Cylinder	1	SBT130-B01	SBT130-B01	SBT130-B01	SBT130-B01	SBT130-B01	SBT130-B01	SBT130-B01
2	Plunger	1	SBT130-B02	SBT130-B02	SBT130-B02	SBT130-B02	SBT130-B02	SBT130-B02	SBT130-B02
3	Thread adaptor	1	SBT-130T 2_1/2"	SBT-130T 2_3/4"	SBT-130T M60	SBT-130T M64	SBT-130T M68	SBT-130T M72	SBT-130T M76
4	Bridge	1	SBT-130J	SBT-130J	SBT-130J	SBT-130J	SBT-130J	SBT-130J	SBT-130J
5	Hex Socket	1	SBT-130H 100	SBT-130H 108	SBT-130H 90	SBT-130H 95	SBT-130H 100	SBT-130H 105	SBT-130H 110
6	bolt	3	XNSETM06-12-N	XNSETM06-12-N	XNSETM06-12-N	XNSETM06-12-N	XNSETM06-12-N	XNSETM06-12-N	XNSETM06-12-N
* 7	back-up ring	1	SBT130-B07	SBT130-B07	SBT130-B07	SBT130-B07	SBT130-B07	SBT130-B07	SBT130-B07
* 8	back-up ring	1	SBT130-B06	SBT130-B06	SBT130-B06	SBT130-B06	SBT130-B06	SBT130-B06	SBT130-B06
* 9	O ring	1	XBP110-90-NOK	XBP110-90-NOK	XBP110-90-NOK	XBP110-90-NOK	XBP110-90-NOK	XBP110-90-NOK	XBP110-90-NOK
* 10	O ring	1	XBP160-90-NOK	XBP160-90-NOK	XBP160-90-NOK	XBP160-90-NOK	XBP160-90-NOK	XBP160-90-NOK	XBP160-90-NOK
11	nipple	2	SBTN-G1412G1412E	SBTN-G1412G1412E	SBTN-G1412G1412E	SBTN-G1412G1412E	SBTN-G1412G1412E	SBTN-G1412G1412E	SBTN-G1412G1412E
12	Coupler-male	1	SBT-CE116-M	SBT-CE116-M	SBT-CE116-M	SBT-CE116-M	SBT-CE116-M	SBT-CE116-M	SBT-CE116-M
13	stop ring	1	SBT130-B08	SBT130-B08	SBT130-B08	SBT130-B08	SBT130-B08	SBT130-B08	SBT130-B08
14	nut-turning bar	1	XJSBT-16	XJSBT-16	XJSBT-16	XJSBT-16	XJSBT-16	XJSBT-16	XJSBT-16
15	Coupler-female	1	SBT-CE116-F	SBT-CE116-F	SBT-CE116-F	SBT-CE116-F	SBT-CE116-F	SBT-CE116-F	SBT-CE116-F

Maked with * are contained in Repair Kit.



Item	Product	Q'ty	2-3/4"	3"	M72	M76	M80
			Part Number	Part Number	Part Number	Part Number	Part Number
1	Cylinder	1	SBT160-B01	SBT160-B01	SBT160-B01	SBT160-B01	SBT160-B01
2	Plunger	1	SBT160-B02	SBT160-B02	SBT160-B02	SBT160-B02	SBT160-B02
3	Thread adaptor	1	SBT-160T 2 3/4"	SBT-160T 3"	SBT-160T M72	SBT-160T M76	SBT-160T M80
4	Bridge	1	SBT-160J	SBT-160J	SBT-160J	SBT-160J	SBT-160J
5	Hex Socket	1	SBT-160H 108	SBT-160H 118	SBT-160H 105	SBT-160H 110	SBT-160H 115
6	bolt	3	XNSETM06-12-N	XNSETM06-12-N	XNSETM06-12-N	XNSETM06-12-N	XNSETM06-12-N
* 7	back-up ring	1	SBT160-B07	SBT160-B07	SBT160-B07	SBT160-B07	SBT160-B07
* 8	back-up ring	1	SBT160-B06	SBT160-B06	SBT160-B06	SBT160-B06	SBT160-B06
* 9	O ring	1	XBP125-90-NOK	XBP125-90-NOK	XBP125-90-NOK	XBP125-90-NOK	XBP125-90-NOK
* 10	O ring	1	XBP180-90-NOK	XBP180-90-NOK	XBP180-90-NOK	XBP180-90-NOK	XBP180-90-NOK
11	nipple	2	SBTN-G1412G1412E	SBTN-G1412G1412E	SBTN-G1412G1412E	SBTN-G1412G1412E	SBTN-G1412G1412E
12	Coupler-male	1	SBT-CE116-M	SBT-CE116-M	SBT-CE116-M	SBT-CE116-M	SBT-CE116-M
13	stop ring	1	SBT160-B08	SBT160-B08	SBT160-B08	SBT160-B08	SBT160-B08
14	nut-turning bar	1	XJSBT-16	XJSBT-16	XJSBT-16	XJSBT-16	XJSBT-16
15	Coupler-female	1	SBT-CE116-F	SBT-CE116-F	SBT-CE116-F	SBT-CE116-F	SBT-CE116-F

Maked with * are contained in Repair Kit.



Item	Product	Q'ty	3-1/4"	3-1/2"	3-3/4"	M80	M85	M90	M95	M100
			Part Number	Part Number	Part Number	Part Number	Part Number	Part Number	Part Number	Part Number
1	Cylinder	1	SBT200-B01	SBT200-B01	SBT200-B01	SBT200-B01	SBT200-B01	SBT200-B01	SBT200-B01	SBT200-B01
2	Plunger	1	SBT200-B02	SBT200-B02	SBT200-B02	SBT200-B02	SBT200-B02	SBT200-B02	SBT200-B02	SBT200-B02
3	Thread adaptor	1	SBT-200T 3 1/4"	SBT-200T 3 1/2"	SBT-200T 3 3/4"	SBT-200T M80	SBT-200T M85	SBT-200T M90	SBT-200T M95	SBT-200T M100
4	Bridge	1	SBT-200J	SBT-200J	SBT-200J	SBT-200J	SBT-200J	SBT-200J	SBT-200J	SBT-200J
5	Hex Socket	1	SBT-200H 127	SBT-200H 137	SBT-200H 146	SBT-200H 115	SBT-200H 120	SBT-200H 130	SBT-200H 135	SBT-200H 145
6	bolt	3	XNSETM06-12-N	XNSETM06-12-N	XNSETM06-12-N	XNSETM06-12-N	XNSETM06-12-N	XNSETM06-12-N	XNSETM06-12-N	XNSETM06-12-N
* 7	back-up ring	1	SBT200-B07	SBT200-B07	SBT200-B07	SBT200-B07	SBT200-B07	SBT200-B07	SBT200-B07	SBT200-B07
* 8	back-up ring	1	SBT200-B06	SBT200-B06	SBT200-B06	SBT200-B06	SBT200-B06	SBT200-B06	SBT200-B06	SBT200-B06
* 9	O ring	1	XBP135-90-NOK	XBP135-90-NOK	XBP135-90-NOK	XBP135-90-NOK	XBP135-90-NOK	XBP135-90-NOK	XBP135-90-NOK	XBP135-90-NOK
* 10	O ring	1	XBP200-90-NOK	XBP200-90-NOK	XBP200-90-NOK	XBP200-90-NOK	XBP200-90-NOK	XBP200-90-NOK	XBP200-90-NOK	XBP200-90-NOK
* 11	nipple	2	SBTN-G1412G1412E	SBTN-G1412G1412E	SBTN-G1412G1412E	SBTN-G1412G1412E	SBTN-G1412G1412E	SBTN-G1412G1412E	SBTN-G1412G1412E	SBTN-G1412G1412E
12	Coupler-male	1	SBT-CE116-M	SBT-CE116-M	SBT-CE116-M	SBT-CE116-M	SBT-CE116-M	SBT-CE116-M	SBT-CE116-M	SBT-CE116-M
13	stop ring	1	SBT200-B08	SBT200-B08	SBT200-B08	SBT200-B08	SBT200-B08	SBT200-B08	SBT200-B08	SBT200-B08
14	nut-turning bar	1	XJSBT-16	XJSBT-16	XJSBT-16	XJSBT-16	XJSBT-16	XJSBT-16	XJSBT-16	XJSBT-16
15	Coupler-female	1	SBT-CE116-F	SBT-CE116-F	SBT-CE116-F	SBT-CE116-F	SBT-CE116-F	SBT-CE116-F	SBT-CE116-F	SBT-CE116-F

Maked with * are contained in Repair Kit.