



編號	品名	ASM-2		ASM-4	
		數量	品號	數量	品號
1	高壓磁軸	2	SV82-A03	4	SV82-A03
2	接頭	2	SV82-A02	4	SV82-A02
3	防塵帽	2	SV82SUS-A05	4	SV82SUS-A05
4	背托環	2	XGP006	4	XGP006
5	O型環	2	XBP006-90-NOK	4	XBP006-90-NOK
6	銅華司	2	XWC14-10-1.2T	4	XWC14-10-1.2T
7	螺柱	2	XNCAPM05-12	4	XNCAPM05-12
8	扳桿	2	ASM2-A02	4	ASM2-A02
9	本體	1	ASM4-A01	1	ASM4-A01
10	鋼珠	1	XM5/16	2	XM5/16
11	螺柱	1	XNSETM10-12	2	XNSETM10-12

* 修理包

Item	Product	ASM-2		ASM-4	
		Q'ty	Part No.	Q'ty	Part No.
1	H.P.axle	2	SV82-A03	4	SV82-A03
2	connector	2	SV82-A02	4	SV82-A02
3	dust cover	2	SV82SUS-A05	4	SV82SUS-A05
* 4	back-up ring	2	XGP006	4	XGP006
* 5	O-ring	2	XBP006-90-NOK	4	XBP006-90-NOK
* 6	copper washer	2	XWC14-10-1.2T	4	XWC14-10-1.2T
7	bolt	2	XNCAPM05-12	4	XNCAPM05-12
8	handle	2	ASM2-A02	4	ASM2-A02
9	body	1	ASM2-A01	1	ASM4-A01
10	steel ball	1	XM5/16	2	XM5/16
11	bolt	1	XNSETM10-12	2	XNSETM10-12

* repair kit

