




項次	零件名稱	數量	規格
1	本體	1	SKM200-B01
2	彈簧蓋-下	1	SKM200-B02
3	O-Ring	1	XBG150
4	背托環	1	XGP175-2T
5	彈簧	6	XF0.6-D9.1-19L-7T
6	彈簧蓋-上	1	SKM200-B03
7	螺栓	1	XNFM05-16
8	主軸	1	SKM200-B04
9	背托環	1	XGP175-2T
10	O-Ring	1	XBG150
11	螺栓	1	XNCAPM04-4
12	平鍵	2	XWC8-10.7-1.2
13	上螺帽	1	SKM200-B05
14	螺帽提把	1	SKM200-B06
15	螺栓	4	XNFM08-15T
16	護板	2	SKM200-B07
17	螺栓	4	XNFM08-15T
18	提把	2	SKM200-B08
19	螺栓	4	XNFM08-15T
20	入口螺栓	1	XNFM08-10T
21	安全閥	1	XFM5
22	快速接頭	1	SQB-3/8UF
23	背托環	1	XGP175-2T
24	O-Ring	1	XBG150
25	底座	1	XWM05
26	螺栓	2	XNFM08-2T
27	螺栓	12	XNFM06-10T