


適用範圍：
超高壓手動泵浦

適用型號系列：SPHH-1612, SPHH-2012,
SPHH-2512




編號	品名	品號	數量
1	泵浦頭	SPHP-A-A1	1
2	油箱	SPH1200-AA1	1
3	連接桿	SPH1200-A06	1
4	尾蓋	SPH1012-A08	1
5	O形環	XBG060	2
6	濾網	XLD10-50	1
7	O形環	XBAS115	1
8	尾蓋螺帽	SPH1200-A01	1
9	洩壓閥組	SPHP-A-A2	1
10	六角華司	A3012-B35-TH20A	1
11	六角油封	A3012-B36-TH20A	1
12	插鎖-長	SPHP-A02	1
13	C形扣環	XAS09	1
14	O形環	XBP008-NOK	1
15	背托環	XGP008	1
16	油泵螺柱	SPHP-A03	1
17	O形環	XBP028-NOK	1
18	背托環	XGP028	1
19	油泵軸	SPHP-A-A2	1
20	插鎖-短	SPHP-A04	1
21	搖桿座	SPH1012-A10	1
22	搖桿	XJSPH-1012A	1
23	低壓襯	SPHP-A06	1
24	低壓彈簧	XF1.6-D7.8-16.5-8T=	1
25	O形環	XBAS203	2
26	高低壓螺柱	SPHP-A05	2
27	高壓襯	SPHP-A07	1
28	高壓彈簧	XF2.2-D3-13.5-6T=	1
29	鋼珠	XM5/32	1
30	鋼珠	XM7/32	3
31	彈簧	SPHP-A08	1
32	鋼珠	XM5/16	3
33	SET螺柱	XNSET-M10-10	2
34	彈簧	SPHP-A09	2
35	鋼珠	XM13/32	1
36	SET螺柱	XNSET1/2"-3/8"	1
37	鋼珠	XM1/4	1
38	SET螺柱	XNSETM08-08	1

* 修理包

適用範圍：
超高壓手動泵浦

適用型號系列:SPHH-1620





編號	品名	品號	數量
1	泵浦頭	SPHP-A-A1	1
2	油箱	SPH2000-AA1	1
3	連接桿	SPH1200-A06	1
4	尾蓋	SPH1012-A08	1
5	O形環	XBG060	2
6	濾網	XLD10-45	1
7	O形環	XBAS115	1
8	尾蓋螺帽	SPH1200-A01	1
9	洩壓閥組	SPHP-A-A2	1
10	六角華司	A3012-B35-T20A	1
11	六角油封	A3012-B36-T20A	1
12	插鎖-長	SPHP-A02	1
13	C形扣環	XAS09	1
14	O形環	XBPO08-NOK	1
15	背托環	XGP008	1
16	油泵螺柱	SPHP-A03	1
17	O形環	XBPO28-NOK	1
18	背托環	XGP028	1
19	油泵軸	SPHP-A-A2	1
20	插鎖-短	SPHP-A04	1
21	搖柄座	SPH1012-A10	1
22	搖桿	XJSPH-1412	1
23	低壓襯	SPHP-A06	1
24	低壓彈簧	XF1.6-D7.8-16.5-8T=	1
25	O形環	XBAS203	2
26	高低壓螺柱	SPHP-A05	2
27	高壓襯	SPHP-A07	1
28	高壓彈簧	XF2.2-D3-13.5-6T=	1
29	鋼珠	XM5/32	1
30	鋼珠	XM7/32	3
31	彈簧	SPHP-A08	1
32	鋼珠	XM5/16	3
33	SET螺柱	XNSET-M10-10	2
34	彈簧	SPHP-A09	2
35	鋼珠	XM13/32	1
36	SET螺柱	XNSET1/2"-3/8"	1
37	鋼珠	XM1/4	1
38	SET螺柱	XNSETM08-08	1

* 修理包

Item	Description	Part	Q'ty
1	pump head	SPHP-A-A1	1
2	oil tank	SPH1200-AA1	1
3	connect rod	SPH1200-A06	1
4	end cover	SPH1012-A08	1
5	O-ring	XBG060	2
6	filter net	XLD10-50	1
7	O-ring	XBAS115	1
8	cover nut	SPH1200-A01	1
9	release vavle	SPHP-A-A2	1
10	hex. Washer	A3012-B35-TH20A	1
11	hex. Seal	A3012-B36-TH20A	1
12	fixed bolt-long	SPHP-A02	1
13	C ring	XAS09	1
14	O-ring	XP008-NOK	1
15	back-up ring	XGP008	1
16	plunger bolt	SPHP-A03	1
17	O-ring	XP028-NOK	1
18	back-up ring	XGP028	1
19	rod	SPHP-A-A2	1
20	fixed bolt-short	SPHP-A04	1
21	rocker joint	SPH1012-A10	1
22	rocker bar	XJSPH-1012A	1
23	L.P bush	SPHP-A06	1
24	L.P spring	XF1.6-D7.8-16.5-8T=	1
25	O-ring	XBAS203	2
26	H.P bolt	SPHP-A05	2
27	H.P bush	SPHP-A07	1
28	H.P spring	XF2.2-D3-13.5-6T=	1
29	steel ball	XM5/32	1
30	steel ball	XM7/32	3
31	spring	SPHP-A08	1
32	steel ball	XM5/16	3
33	SET bolt	XNSET-M10-10	2
34	spring	SPHP-A09	2
35	steel ball	XM13/32	1
36	SET bolt	XNSET1/2"-3/8"	1
37	steel ball	XM1/4	1
38	SET bolt	XNSETM08-08	1

* Repair kit





Item	Part	Part Number	Q'ty
1	pump head	SPHP-A-A1	1
2	oil tank	SPH2000-AA1	1
3	connect rod	SPH1200-A06	1
4	end cover	SPH1012-A08	1
5	O-ring	XBG060	2
6	filter net	XLD10-45	1
7	O-ring	XBAS115	1
8	cover nut	SPH1200-A01	1
9	release valve	SPHP-A-A2	1
10	hex. Washer	A3012-B35-T20A	1
11	hex. Seal	A3012-B36-T20A	1
12	fixed bolt-long	SPHP-A02	1
13	C ring	XAS09	1
14	O-ring	XBP008-NOK	1
15	back-up ring	XGP008	1
16	plunger bolt	SPHP-A03	1
17	O-ring	XBP028-NOK	1
18	back-up ring	XGP028	1
19	rod	SPHP-A-A2	1
20	fixed bolt-short	SPHP-A04	1
21	rocker joint	SPH1012-A10	1
22	rocker bar	XJSPH-1412	1
23	L.P bush	SPHP-A06	1
24	L.P spring	XF1.6-D7.8-16.5-8T=	1
25	O-ring	XBAS203	2
26	H.P bolt	SPHP-A05	2
27	H.P bush	SPHP-A07	1
28	H.P spring	XF2.2-D3-13.5-6T=	1
29	steel ball	XM5/32	1
30	steel ball	XM7/32	3
31	spring	SPHP-A08	1
32	steel ball	XM5/16	3
33	SET bolt	XNSET-M10-10	2
34	spring	SPHP-A09	2
35	steel ball	XM13/32	1
36	SET bolt	XNSET1/2"-3/8"	1
37	steel ball	XM1/4	1
38	SET bolt	XNSETM08-08	1

* Repair Kit