




項次	品名	數量	品號
1	油路本體	1	SPE3000A-B01
2	低壓泵油組	1	SPE-A-3000A3
3	O型環	1	XBP008-90-NOK
4	油泵塊組	1	SPE-A-3000A2
5	排油管	1	SPE3000A-B02
6	螺栓	3	XNCAPM06-16
7	螺栓	4	XNCAPM06-60
8	油管轉接頭A	1	SPE3000A-B07A
9	安全閥組	1	SPE-A-3000A5
10	回油塊組	1	SPE-A-3000A4
11	螺栓	4	XNCAPM05-60
12	偏心軸組	1	SPE-A-3000A6
13	C型扣環	1	XAR52
14	電磁閥連接板	1	SPE3000A-C03
15	電磁閥壓板組	1	SPE-A-3000A7
16	螺栓	4	XNCAPM05-25
17	電磁閥墊高塊	2	SPE3000A-C05
18	電磁閥桿	1	SPE3000A-C02
19	電磁閥本體	1	SPE3000A-C01
20	螺栓	2	XNCAPM05-30
21	馬達110V/220V	1	SPE3000A-D01A/B
22	螺栓	4	XNCAPM05-40
23	R角縫隙膠圈	1	XCSPE3000-1
24	油箱組	1	SPE-A-3000A1
25	通氣螺栓	1	SPE-A-3000A-1
26	螺栓	6	XNCAPM05-16
27	外蓋組	1	SPE-A-3000A
28	螺栓	4	XNCAPM05-45






項次	品名	數量	品號
1	油路本體	1	SPE3000A-B01
2	低壓油泵組	1	SPE-A-3000B3
3	O型環	1	XBP008-90-NOK
4	油泵塊組	1	SPE-B-3000B2
5	增壓回油組	1	SPE-B-3000B1
6	螺栓	3	XNCAPM06-16
7	螺栓	4	XNCAPM06-60
8	油管轉接頭B	1	SPE3000A-B07B
9	安全閥組	1	SPE-A-3000A5
10	螺栓	1	XNSETM05-16
11	鋼珠	1	XM3/16
12	鋼珠壓板	1	SPE3000D-W11
13	螺栓	2	XNCAPM05-15
14	螺栓	6	XNCAPM05-20
15	偏心軸組	1	SPE-A-3000A6
16	C型扣環	1	XAR52
17	馬達110V/220V	1	SPE3000A-D01A/B
18	螺栓	4	XNCAPM05-40
19	R角縫隙膠圈	1	XCSPE3000-1
20	油箱組	1	SPE-A-3000A1
21	通氣螺栓	1	SPE-A-3000A-1
22	外蓋組	1	SPE-A-3000B
23	螺栓	4	XNCAPM05-45





項次	品名	數量	品號
1	油路本體	1	SPE3000A-B01
2	低壓油泵組	1	SPE-A-3000A3
3	O型環	3	XBP008-90-NOK
4	油泵塊組	1	SPE-A-3000A2
5	螺栓	3	XNCAPM06-16
6	螺栓	4	XNCAPM06-60
7	油管轉接頭C	1	SPE3000A-B07C
8	安全閥組	1	SPE-A-3000A5
9	手動洩壓閥組	1	SPE-A-3000C4
10	螺栓	4	XNCAPM05-70
11	螺栓	6	XNCAPM05-20
12	偏心軸組	1	SPE-A-3000A6
13	C型扣環	1	XAR52
14	馬達110V/220V	1	SPE3000A-D01A/B
15	螺栓	4	XNCAPM05-40
16	R角縫隙膠圈	1	XCSPE3000-1
17	油箱組	1	SPE-A-3000A1
18	通氣螺栓	1	SPE-A-3000A-1
19	外蓋組	1	SPE-A-3000C
20	螺栓	4	XNCAPM06-45




項次	品名	數量	品號
1	油路本體	1	SPE3000A-B01
2	低壓油泵組	1	SPE-A-3000A3
3	O型環	3	XBP008-90-NOK
4	油泵塊組	1	SPE-A-3000A2
5	螺栓	3	XNCAPM06-16
6	螺栓	4	XNCAPM06-60
7	安全閥組	1	SPE-A-3000A5
8	方向閥組	1	SVR-D4
9	螺栓	3	XNCAPM06-70
10	偏心軸組	1	SPE-A-3000A6
11	C型扣環	1	XAR52
12	螺栓	6	XNCAPM05-16
13	馬達110V/220V	1	SPE3000A-D01A/B
14	螺栓	4	XNCAPM05-40
15	R角縫隙膠圈	1	XCSPE3000-1
16	油箱組	1	SPE-A-3000A1
17	通氣螺栓	1	SPE-A-3000A-1
18	外蓋組	1	SPE-A-3000D
19	螺栓	4	XNCAPM05-45
20	轉接頭	2	SPE3000-I05

Model No.: SPE-3000A




Model No.: SPE-3000C

電路圖





油路圖




Item	Description	Q'ty	Part No.
1	body	1	SPE3000A-B01
2	L.P pump	1	SPE-A-3000A3
3	O-ring	1	XBP008-90-NOK
4	pump block	1	SPE-A-3000A2
5	oil tube	1	SPE3000A-B02
6	bolt	3	XNCAPM06-16
7	bolt	4	XNCAPM06-60
8	hose connect(A)	1	SPE3000A-B07A
9	safety valve assembly	1	SPE-A-3000A5
10	oil return	1	SPE-A-3000A4
11	bolt	4	XNCAPM05-60
12	bais axle assembly	1	SPE-A-3000A6
13	C type ring	1	XAR52
14	solenoid valve plate	1	SPE3000A-C03
15	solenoid valve block	1	SPE-A-3000A7
16	bolt	4	XNCAPM05-25
17	solenoid valve auxiliary	2	SPE3000A-C05
18	solenoid valve bar	1	SPE3000A-C02
19	solenoid valve body	1	SPE3000A-C01
20	bolt	2	XNCAPM05-30
21	Motor 110V/220V	1	SPE3000A-D01A/B
22	bolt	4	XNCAPM05-40
23	Radian rubber space	1	XCSPE3000-1
24	oil tank	1	SPE-A-3000A1
25	vent bolt	1	SPE-A-3000A-1
26	bolt	6	XNCAPM05-16
27	cover assembly	1	SPE-A-3000A
28	bolt	4	XNCAPM05-45

Item 19:SPE3000A-C01 for 110V
SPE3000A-C01A for 220V-50hz
SPE3000A-C01B for 220C-60Hz






Item	Description	Q'ty	Part No.
1	body	1	SPE3000A-B01
2	L.P pump	1	SPE-A-3000B3
3	O-ring	1	XBP008-90-NOK
4	pump block	1	SPE-B-3000B2
5	add press oil return	1	SPE-B-3000B1
6	bolt	3	XNCAPM06-16
7	bolt	4	XNCAPM06-60
8	hose connect(B)	1	SPE3000A-B07B
9	safety valve assembly	1	SPE-A-3000A5
10	bolt	1	XNSETM05-16
11	steel ball	1	XM3/16
12	steel ball plate	1	SPE3000D-W11
13	bolt	2	XNCAPM05-15
14	bolt	6	XNCAPM05-20
15	bais axle assembly	1	SPE-A-3000A6
16	C type ring	1	XAR52
17	Motor 110V/220V	1	SPE3000A-D01A/B
18	bolt	4	XNCAPM05-40
19	Radian rubber space	1	XCSPE3000-1
20	oil tank	1	SPE-A-3000A1
21	vent bolt	1	SPE-A-3000A-1
22	cover assembly	1	SPE-A-3000B
23	bolt	4	XNCAPM05-45




Item	Description	Q'ty	Part No.
1	body	1	SPE3000A-B01
2	L.P pump	1	SPE-A-3000A3
3	O-ring	3	XBP008-90-NOK
4	pump block	1	SPE-A-3000A2
5	bolt	3	XNCAPM06-16
6	bolt	4	XNCAPM06-60
7	hose connect(C)	1	SPE3000A-B07C
8	safety valve assembly	1	SPE-A-3000A5
9	manual release valve	1	SPE-A-3000C4
10	bolt	4	XNCAPM05-70
11	bolt	6	XNCAPM05-20
12	bais axle assembly	1	SPE-A-3000A6
13	C type ring	1	XAR52
14	Motor 110V/220V	1	SPE3000A-D01A/B
15	bolt	4	XNCAPM05-40
16	Radian rubber space	1	XCSPE3000-1
17	oil tank	1	SPE-A-3000A1
18	vent bolt	1	SPE-A-3000A-1
19	cover assembly	1	SPE-A-3000C
20	bolt	4	XNCAPM06-45




Item	Description	Q'ty	Part No.
1	body	1	SPE3000A-B01
2	L.P pump	1	SPE-A-3000A3
3	O-ring	3	XBP008-90-NOK
4	pump block	1	SPE-A-3000A2
5	bolt	3	XNCAPM06-16
6	bolt	4	XNCAPM06-60
7	safety valve assembly	1	SPE-A-3000A5
8	Manual control valve	1	SVR-D4
9	bolt	3	XNCAPM06-70
10	bais axle assembly	1	SPE-A-3000A6
11	C type ring	1	XAR52
12	bolt	6	XNCAPM05-16
13	Motor 110V/220V	1	SPE3000A-D01A/B
14	bolt	4	XNCAPM05-40
15	Radian rubber space	1	XCSPE3000-1
16	oil tank	1	SPE-A-3000A1
17	vent bolt	1	SPE-A-3000A-1
18	cover assembly	1	SPE-A-3000D
19	bolt	4	XNCAPM05-45
20	connect	2	SPE3000-I05

Model No.: SPE-3000A

Circuit Diagram




Oil path Diagram



Model No.: SPE-3000C

Circuit Diagram



Oil path Diagram

