





| 編碼   | 品名    | 數量 | 品號             |
|------|-------|----|----------------|
| 1    | 油壓缸本體 | 1  | SRX2-C01       |
| 2    | 主軸    | 1  | SRX2-C02       |
| 3    | 塞底    | 1  | SRX2-C03       |
| * 4  | 背托環   | 1  | XG3023         |
| * 5  | O形環   | 1  | XBAS119-90-NOK |
| * 6  | O形環   | 1  | XBS025         |
| * 7  | 背托環   | 1  | XG025-028-1.25 |
| * 8  | O形環   | 1  | XBP016-90-NOK  |
| * 9  | 背托環   | 1  | XBP016         |
| 10   | 半月推塊  | 2  | SRX2-C06       |
| 11   | 彈簧銷   | 1  | XA3-16         |
| 12   | 止動螺栓  | 1  | SRX2-C12       |
| 13   | 連結插銷  | 1  | SRX2-C09       |
| 14   | 塞頭    | 2  | XNPT1/16       |
| 15   | 接桿    | 1  | SRX2-C04       |
| * 16 | O形環   | 3  | XBP005-90-NOK  |
| * 17 | 背托環   | 2  | XGP005         |
| 18   | 旋轉軸座  | 1  | SRX2-C05       |
| 19   | 螺栓    | 4  | XNCAPM05-15    |
| * 20 | O形環   | 3  | XBP018-PU      |
| * 21 | 背托環   | 4  | XHP018         |
| 22   | 出入口軸塊 | 1  | SMX3-A00       |
| 23   | C形扣環  | 1  | XAS015         |
| * 24 | 背托環   | 4  | XGAS014        |
| * 25 | O形環   | 4  | XBPAS014-PU    |

\* 修理包





|      |        | SRX-2 L30 |                     | SRX-2 L32           |                     | SRX-2 L36           |                     | SRX-2 L41           |                     | SRX-2 L46           |    | SRX-2 L50 |    | SRX-2 L55 |          | SRX-2 L60 |          |
|------|--------|-----------|---------------------|---------------------|---------------------|---------------------|---------------------|---------------------|---------------------|---------------------|----|-----------|----|-----------|----------|-----------|----------|
| 編號   | 品名     | 數量        | 品號                  | 品號                  | 品號                  | 品號                  | 品號                  | 品號                  | 品號                  | 品號                  | 品號 | 品號        | 品號 | Part No.  | Part No. | Part No.  | Part No. |
| 1    | 兩側外板-右 | 1         | SRX2-L30-L1         | SRX2-L32-L1         | SRX2-L36-L1         | SRX2-L41-L1         | SRX2-L46-L1         | SRX2-L50-L1         | SRX2-L55-L1         | SRX2-L60-L1         |    |           |    |           |          |           |          |
| 2    | 兩側外板-左 | 1         | SRX2-L30-L2         | SRX2-L32-L2         | SRX2-L36-L2         | SRX2-L41-L2         | SRX2-L46-L2         | SRX2-L50-L2         | SRX2-L55-L2         | SRX2-L60-L2         |    |           |    |           |          |           |          |
| 3    | 銅襯     | 2         | SRX2-L30-L12        | SRX2-L32-L12        | SRX2-L36-L12        | SRX2-L41-L12        | SRX2-L46-L12        | SRX2-L50-L12        | SRX2-L55-L12        | SRX2-L60-L12        |    |           |    |           |          |           |          |
| 4    | 搖座     | 1         | SRX2-L30-L3         | SRX2-L32-L3         | SRX2-L36-L3         | SRX2-L41-L3         | SRX2-L46-L3         | SRX2-L50-L3         | SRX2-L55-L3         | SRX2-L60-L3         |    |           |    |           |          |           |          |
| 5    | 棘輪     | 1         | SRX2-L30-L6         | SRX2-L32-L6         | SRX2-L36-L6         | SRX2-L41-L6         | SRX2-L46-L6         | SRX2-L50-L6         | SRX2-L55-L6         | SRX2-L60-L6         |    |           |    |           |          |           |          |
| 6    | 驅動齒    | 1         | SRX2-L30-L7         | SRX2-L32-L7         | SRX2-L36-L7         | SRX2-L41-L7         | SRX2-L46-L7         | SRX2-L50-L7         | SRX2-L55-L7         | SRX2-L60-L7         |    |           |    |           |          |           |          |
| 7    | 驅動齒彈簧  | 1         | XF0.6-D4.5-13.5L-8T | XF0.6-D4.5-13.5L-8T | XF0.6-D4.5-13.5L-8T | XF0.6-D4.5-13.5L-8T | XF0.6-D4.5-13.5L-8T | XF0.6-D4.5-13.5L-8T | XF0.6-D4.5-13.5L-8T | XF0.6-D4.5-13.5L-8T |    |           |    |           |          |           |          |
| 8    | 反作用彈簧  | 1         | XF-SRX2             | XFSRX2              | XFSRX2              | XFSRX2              | XFSRX2              | XFSRX2              | XFSRX2              | XFSRX2              |    |           |    |           |          |           |          |
| 9    | 拉桿     | 1         | SRX2-L30-L4         | SRX2-L4             | SRX2-L4             | SRX2-L4             | SRX2-L4             | SRX2-L4             | SRX2-L4             | SRX2-L4             |    |           |    |           |          |           |          |
| 10   | 彈簧銷    | 1         | XA1/8x5/8L          | XA3-16              | XA3-16              | XA3-16              | XA3-16              | XA3-16              | XA3-16              | XA3-16              |    |           |    |           |          |           |          |
| 11   | 上隔塊    | 1         | SRX2-L30-L8         | SRX2-L30-L8         | SRX2-L30-L8         | SRX2-L30-L8         | SRX2-L30-L8         | SRX2-L30-L8         | SRX2-L30-L8         | SRX2-L30-L8         |    |           |    |           |          |           |          |
| 12   | 下隔塊    | 1         | SRX2-L30-L10        | SRX2-L10            | SRX2-L10            | SRX2-L10            | SRX2-L10            | SRX2-L10            | SRX2-L10            | SRX2-L10            |    |           |    |           |          |           |          |
| 13   | 定位銷    | 2         | SRX2-L30-L11        | SRX2-L11            | SRX2-L11            | SRX2-L11            | SRX2-L11            | SRX2-L11            | SRX2-L11            | SRX2-L11            |    |           |    |           |          |           |          |
| * 14 | CAP螺栓  | 4         | XNCAP#8-32x3/8L     | XNCAP#8-32UNC-3/8"  | XNCAP#8-32UNC-3/8"  | XNCAP#8-32UNC-3/8"  | XNCAP#8-32UNC-3/8"  | XNCAP#8-32UNC-3/8"  | XNCAP#8-32UNC-3/8"  | XNCAP#8-32UNC-3/8"  |    |           |    |           |          |           |          |
| * 15 | 血型螺栓   | 4         | XNF1/4"-20x5/8L     | XNF1/4"-20UNC-1/2"  | XNF1/4"-20UNC-1/2"  | XNF1/4"-20UNC-1/2"  | XNF1/4"-20UNC-1/2"  | XNF1/4"-20UNC-1/2"  | XNF1/4"-20UNC-1/2"  | XNF1/4"-20UNC-1/2"  |    |           |    |           |          |           |          |
| * 16 | 半圓頭螺栓  | 2         | XNBH#8-32x1/4L      | XNBH#8-32UNC-1/4L"  | XNBH#8-32UNC-1/4L"  | XNBH#8-32UNC-1/4L"  | XNBH#8-32UNC-1/4L"  | XNBH#8-32UNC-1/4L"  | XNBH#8-32UNC-1/4L"  | XNBH#8-32UNC-1/4L"  |    |           |    |           |          |           |          |
| 17   | 保護蓋    | 1         | SRX2-L30-L13        | SRX2-L13            | SRX2-L13            | SRX2-L13            | SRX2-L13            | SRX2-L13            | SRX2-L13            | SRX2-L13            |    |           |    |           |          |           |          |

\* 修理包零件


適用範圍：  
雙動六角中空液壓扳手

適用型號：SRX-4  
SRX-4C 缸體




| 編碼   | 品名     | 數量 | 品號                |
|------|--------|----|-------------------|
| 1    | 本體     | 1  | SRX4-C01          |
| 2    | 主軸     | 1  | SRX4-C02          |
| 3    | 尾蓋     | 1  | SRX4-C03          |
| * 4  | 背托環    | 2  | XGP030            |
| * 5  | O形環    | 2  | XBP030-90-NOK     |
| * 6  | O形環    | 1  | XBP022-90-NOK     |
| * 7  | 背托環    | 1  | XGP022            |
| 8    | 半月推塊   | 2  | SRX4-C06          |
| 9    | 塞頭     | 2  | XNPT1/16          |
| 10   | 接桿     | 1  | SRX2-C04          |
| * 11 | 背托環    | 2  | XGP005            |
| * 12 | O形環    | 2  | XBP005            |
| * 13 | O形環    | 1  | XBP004            |
| 14   | 旋轉軸座   | 1  | SRX2-C05          |
| 15   | 螺栓     | 4  | XNCAPM05-15       |
| * 16 | 背托環    | 4  | XHP018            |
| * 17 | O形環    | 3  | XBP018-PU         |
| 18   | 出入口軸塊  | 1  | SMX3-A00-4        |
| 19   | C形扣環   | 1  | XAS015            |
| * 20 | 背托環    | 4  | XGAS014           |
| * 21 | O形環    | 4  | XBAS014           |
| 22   | 出入口塊-公 | 1  | SMX3-A00-2        |
| 23   | 出入口塊-母 | 1  | SMX3-A00-3        |
| 24   | 連結插銷   | 1  | SRX4-C09          |
| 25   | 螺栓     | 1  | SRX4-C12          |
| 26   | 彈簧     | 1  | XF0.7-D4.3-5.2-3T |
| 27   | 鋼珠     | 1  | XM3/16            |
| 28   | 彈簧銷    | 1  | XA04-20           |

\* 修理包



|      |        |    | SRX-4 L41        | SRX-4 L46        | SRX-4 L50        | SRX-4 L55        | SRX-4 L60        | SRX-4 L65        | SRX-4 L70        | SRX-4 L75        | SRX-4 L80        |
|------|--------|----|------------------|------------------|------------------|------------------|------------------|------------------|------------------|------------------|------------------|
| 編號   | 品名     | 數量 | 品號               | 品號               | 品號               | 品號               | 品號               | 品號               | 品號               | 品號               | 品號               |
| 1    | 兩側外板-右 | 1  | SRX4-L41-L1      | SRX4-L46-L1      | SRX4-L50-L1      | SRX4-L55-L1      | SRX4-L60-L1      | SRX4-L65-L1      | SRX4-L70-L1      | SRX4-L75-L1      | SRX4-L80-L1      |
| 2    | 兩側外板-左 | 1  | SRX4-L41-L2      | SRX4-L46-L2      | SRX4-L50-L2      | SRX4-L55-L2      | SRX4-L60-L2      | SRX4-L65-L2      | SRX4-L70-L2      | SRX4-L75-L2      | SRX4-L80-L2      |
| 3    | 銅楔     | 2  | SRX4-L41-L12     | SRX4-L46-L12     | SRX4-L50-L12     | SRX4-L55-L12     | SRX4-L60-L12     | SRX4-L65-L12     | SRX4-L70-L12     | SRX4-L75-L12     | SRX4-L80-L12     |
| 4    | 搖座     | 1  | SRX4-L41-L3      | SRX4-L46-L3      | SRX4-L50-L3      | SRX4-L55-L3      | SRX4-L60-L3      | SRX4-L65-L3      | SRX4-L70-L3      | SRX4-L75-L3      | SRX4-L80-L3      |
| 5    | 棘輪     | 1  | SRX4-L41-L6      | SRX4-L46-L6      | SRX4-L50-L6      | SRX4-L55-L6      | SRX4-L60-L6      | SRX4-L65-L6      | SRX4-L70-L6      | SRX4-L75-L6      | SRX4-L80-L6      |
| 6    | 驅動齒    | 1  | SRX4-L41-L7      | SRX4-L46-L7      | SRX4-L50-L7      | SRX4-L55-L7      | SRX4-L60-L7      | SRX4-L65-L7      | SRX4-L70-L7      | SRX4-L75-L7      | SRX4-L80-L7      |
| 7    | 驅動齒彈簧  | 1  | XF0.8-D6.2-15-7T | XF0.8-D6.2-15-7T | XF0.8-D6.2-15-7T | XF0.8-D6.2-15-7T | XF0.8-D6.2-15-7T | XF0.8-D6.2-15-7T | XF0.8-D6.2-15-7T | XF0.8-D6.2-15-7T | XF0.8-D6.2-15-7T |
| 8    | 反作用彈簧  | 1  | XF-SRX4          | XF-SRX4          | XF-SRX4          | XF-SRX4          | XF-SRX4          | XF-SRX4          | XF-SRX4          | XF-SRX4          | XF-SRX4          |
| 9    | 拉桿     | 1  | SRX4-L41-L4      | SRX4-L41-L4      | SRX4-L41-L4      | SRX4-L41-L4      | SRX4-L41-L4      | SRX4-L41-L4      | SRX4-L41-L4      | SRX4-L41-L4      | SRX4-L41-L4      |
| 10   | 彈簧鎖    | 1  | XA1/8x7/8L       | XA1/8x7/8L       | XA1/8x7/8L       | XA1/8x7/8L       | XA1/8x7/8L       | XA1/8x7/8L       | XA1/8x7/8L       | XA1/8x7/8L       | XA1/8x7/8L       |
| 11   | 上隔塊    | 1  | SRX4-L41-L8      | SRX4-L41-L8      | SRX4-L55-L8      | SRX4-L55-L8      | SRX4-L55-L8      | SRX4-L55-L8      | SRX4-L70-L8      | SRX4-L70-L8      | SRX4-L70-L8      |
| 12   | 下隔塊    | 1  | SRX4-L41-L10     | SRX4-L41-L10     | SRX4-L41-L10     | SRX4-L41-L10     | SRX4-L41-L10-1   | SRX4-L41-L10-1   | SRX4-L41-L10-1   | SRX4-L41-L10-1   | SRX4-L41-L10-1   |
| 13   | 定位鎖    | 2  | SRX4-L41-L11     | SRX4-L41-L11     | SRX4-L41-L11     | SRX4-L41-L11     | SRX4-L41-L11     | SRX4-L41-L11     | SRX4-L41-L11     | SRX4-L41-L11     | SRX4-L41-L11     |
| * 14 | CAP螺栓  | 4  | XNCAP#10-32x1/2L | XNCAP#10-32x1/2L | XNCAP#10-32x1/2L | XNCAP#10-32x1/2L | XNCAP#10-32x1/2L | XNCAP#10-32x1/2L | XNCAP#10-32x1/2L | XNCAP#10-32x1/2L | XNCAP#10-32x1/2L |
| * 15 | 皿型螺栓   | 4  | XNF5/16-18x3/4L  | XNF5/16-18x3/4L  | XNF5/16-18x3/4L  | XNF5/16-18x3/4L  | XNF5/16-18x3/4L  | XNF5/16-18x3/4L  | XNF5/16-18x3/4L  | XNF5/16-18x3/4L  | XNF5/16-18x3/4L  |
| * 16 | 半圓頭螺栓  | 2  | XNBH#8-32x1/4L   | XNBH#8-32x1/4L   | XNBH#8-32x1/4L   | XNBH#8-32x1/4L   | XNBH#8-32x1/4L   | XNBH#8-32x1/4L   | XNBH#8-32x1/4L   | XNBH#8-32x1/4L   | XNBH#8-32x1/4L   |
| 17   | 保護蓋    | 1  | SRX4-L41-L13     | SRX4-L41-L13     | SRX4-L41-L13     | SRX4-L41-L13     | SRX4-L41-L13     | SRX4-L41-L13     | SRX4-L41-L13     | SRX4-L41-L13     | SRX4-L41-L13     |

\* 修理包零件




| 編碼   | 品名     | 數量 | 品號                |
|------|--------|----|-------------------|
| 1    | 本體     | 1  | SRX8-C01          |
| 2    | 主軸     | 1  | SRX8-C02          |
| 3    | 尾蓋     | 1  | SRX8-C03          |
| * 4  | O形環    | 2  | XBP040-90-NOK     |
| * 5  | 背托環    | 3  | XGP040            |
| 6    | 半月形推塊  | 2  | SRX8-C06          |
| 7    | 彈簧銷    | 1  | XA05-28           |
| * 8  | 背托環    | 1  | XGP028            |
| * 9  | O形環    | 1  | XBP028-90-NOK     |
| 10   | 接桿     | 1  | SRX2-C04          |
| * 11 | O形環    | 2  | XBP005            |
| * 12 | 背托環    | 2  | XGP005            |
| * 13 | O形環    | 1  | XBP004            |
| 14   | 旋轉軸座   | 1  | SRX2-C05          |
| 15   | 螺栓     | 4  | XNCAPM05-15       |
| * 16 | O形環    | 3  | XBP018-PU         |
| * 17 | 背托環    | 4  | XHP018            |
| 18   | 出入口塊-公 | 1  | SMX3-A00-2        |
| 19   | 出入口塊-母 | 1  | SMX3-A00-3        |
| 20   | 出入口軸塊  | 1  | SMX3-A00-4        |
| 21   | C形扣環   | 1  | XAS015            |
| * 22 | 背托環    | 4  | XGAS014           |
| * 23 | O形環    | 4  | XBAS014           |
| 24   | 螺栓     | 1  | XNSETM06-12       |
| 25   | 彈簧     | 1  | XFQ.7-D4.3-5.2-3T |
| 26   | 鋼珠     | 1  | XM3/16            |

\* 修理包

適用範圍：  
雙動六角中空液壓扳手

適用型號：SRX-8  
SRX-8L 連接體




|      |        | SRX-8 L95 |                  | SRX-8 L100       | SRX-8 L105       |
|------|--------|-----------|------------------|------------------|------------------|
| 編碼   | 品名     | 數量        | 品號               | 品號               | 品號               |
| 1    | 兩側外板-右 | 1         | SRX8-L95-L1-1    | SRX8-L100-L1-1   | SRX8-L105-L1-1   |
| 2    | 兩側外板-左 | 1         | SRX8-L95-L1-2    | SRX8-L100-L1-2   | SRX8-L105-L1-2   |
| 3    | 銅襯     | 2         | SRX8-L95-L12     | SRX8-L100-L12    | SRX8-L105-L12    |
| 4    | 搖座     | 1         | SRX8-L95-L3      | SRX8-L100-L3     | SRX8-L105-L3     |
| 5    | 棘輪     | 1         | SRX8-L95-L6      | SRX8-L100-L6     | SRX8-L105-L6     |
| 6    | 驅動齒    | 1         | SRX8-L95-L7      | SRX8-L100-L7     | SRX8-L105-L7     |
| 7    | 驅動齒彈簧  | 1         | XF0.8-D6.2-10-8T | XF0.8-D6.2-10-8T | XF0.8-D6.2-10-8T |
| 8    | 反作用彈簧  | 1         | XF-SRX8          | XF-SRX8          | XF-SRX8          |
| 9    | 拉桿     | 1         | SRX8-L95-L4      | SRX8-L100-L4     | SRX8-L105-L4     |
| 10   | 彈簧鎖    | 1         | XA4-25           | XA4-25           | XA4-25           |
| 11   | 上隔塊    | 1         | SRX8-L95-L8      | SRX8-L100-L8     | SRX8-L105-L8     |
| 12   | 下隔塊    | 1         | SRX8-L95-L10     | SRX8-L100-L10    | SRX8-L105-L10    |
| 13   | 定位鎖    | 2         | SRX8-L95-L11     | SRX8-L100-L11    | SRX8-L105-L11    |
| * 14 | CAP螺栓  | 4         | XNCAP1/4"-5/8"   | XNCAP1/4"-5/8"   | XNCAP1/4"-5/8"   |
| * 15 | 皿型螺栓   | 4         | XNFF3/8"-1"      | XNFF3/8"-1"      | XNFF3/8"-1"      |
| * 16 | 半圓頭螺栓  | 2         | XNBH#10-32-3/8   | XNBH#10-32-3/8   | XNBH#10-32-3/8   |
| 17   | 保護蓋    | 1         | SRX8-L95-L13     | SRX8-L100-L13    | SRX8-L105-L13    |

\* 修理包零件

|      |        | SRX-8 L50 |                  | SRX-8 L55        | SRX-8 L60        | SRX-8 L65        | SRX-8 L70        | SRX-8 L75        | SRX-8 L80        | SRX-8 L85        | SRX-8 L90        |
|------|--------|-----------|------------------|------------------|------------------|------------------|------------------|------------------|------------------|------------------|------------------|
| 編碼   | 品名     | 數量        | 品號               | 品號               | 品號               | 品號               | 品號               | 品號               | 品號               | 品號               | 品號               |
| 1    | 兩側外板-右 | 1         | SRX8-L50-L1-1    | SRX8-L55-L1-1    | SRX8-L60-L1-1    | SRX8-L65-L1-1    | SRX8-L70-L1-1    | SRX8-L75-L1-1    | SRX8-L80-L1-1    | SRX8-L85-L1-1    | SRX8-L90-L1-1    |
| 2    | 兩側外板-左 | 1         | SRX8-L50-L1-2    | SRX8-L55-L1-2    | SRX8-L60-L1-2    | SRX8-L65-L1-2    | SRX8-L70-L1-2    | SRX8-L75-L1-2    | SRX8-L80-L1-2    | SRX8-L85-L1-2    | SRX8-L90-L1-2    |
| 3    | 銅襯     | 2         | SRX8-L50-L12     | SRX8-L55-L12     | SRX8-L60-L12     | SRX8-L65-L12     | SRX8-L70-L12     | SRX8-L75-L12     | SRX8-L80-L12     | SRX8-L85-L12     | SRX8-L90-L12     |
| 4    | 搖座     | 1         | SRX8-L50-L3      | SRX8-L55-L3      | SRX8-L60-L3      | SRX8-L65-L3      | SRX8-L70-L3      | SRX8-L75-L3      | SRX8-L80-L3      | SRX8-L85-L3      | SRX8-L90-L3      |
| 5    | 棘輪     | 1         | SRX8-L50-L6      | SRX8-L55-L6      | SRX8-L60-L6      | SRX8-L65-L6      | SRX8-L70-L6      | SRX8-L75-L6      | SRX8-L80-L6      | SRX8-L85-L6      | SRX8-L90-L6      |
| 6    | 驅動齒    | 1         | SRX8-L50-L7      | SRX8-L55-L7      | SRX8-L60-L7      | SRX8-L65-L7      | SRX8-L70-L7      | SRX8-L75-L7      | SRX8-L80-L7      | SRX8-L85-L7      | SRX8-L90-L7      |
| 7    | 驅動齒彈簧  | 1         | XF0.8-D6.2-10-8T | XF0.8-D6.2-10-8T | XF0.8-D6.2-10-8T | XF0.8-D6.2-10-8T | XF0.8-D6.2-10-8T | XF0.8-D6.2-10-8T | XF0.8-D6.2-10-8T | XF0.8-D6.2-10-8T | XF0.8-D6.2-10-8T |
| 8    | 反作用彈簧  | 1         | XF-SRX8          | XF-SRX8          | XF-SRX8          | XF-SRX8          | XF-SRX8          | XF-SRX8          | XF-SRX8          | XF-SRX8          | XF-SRX8          |
| 9    | 拉桿     | 1         | SRX8-L50-L4      | SRX8-L55-L4      | SRX8-L60-L4      | SRX8-L65-L4      | SRX8-L70-L4      | SRX8-L75-L4      | SRX8-L80-L4      | SRX8-L85-L4      | SRX8-L90-L4      |
| 10   | 彈簧鎖    | 1         | XA4-25           | XA4-25           | XA4-25           | XA4-25           | XA4-25           | XA4-25           | XA4-25           | XA4-25           | XA4-25           |
| 11   | 上隔塊    | 1         | SRX8-L50-L8      | SRX8-L55-L8      | SRX8-L60-L8      | SRX8-L65-L8      | SRX8-L70-L8      | SRX8-L75-L8      | SRX8-L80-L8      | SRX8-L85-L8      | SRX8-L90-L8      |
| 12   | 下隔塊    | 1         | SRX8-L50-L10     | SRX8-L55-L10     | SRX8-L60-L10     | SRX8-L65-L10     | SRX8-L70-L10     | SRX8-L75-L10     | SRX8-L80-L10     | SRX8-L85-L10     | SRX8-L90-L10     |
| 13   | 定位鎖    | 2         | SRX8-L50-L11     | SRX8-L55-L11     | SRX8-L60-L11     | SRX8-L65-L11     | SRX8-L70-L11     | SRX8-L75-L11     | SRX8-L80-L11     | SRX8-L85-L11     | SRX8-L90-L11     |
| * 14 | CAP螺栓  | 4         | XNCAP1/4"-5/8"   | XNCAP1/4"-5/8"   | XNCAP1/4"-5/8"   | XNCAP1/4"-5/8"   | XNCAP1/4"-5/8"   | XNCAP1/4"-5/8"   | XNCAP1/4"-5/8"   | XNCAP1/4"-5/8"   | XNCAP1/4"-5/8"   |
| * 15 | 皿型螺栓   | 4         | XNFF3/8"-1"      | XNFF3/8"-1"      | XNFF3/8"-1"      | XNFF3/8"-1"      | XNFF3/8"-1"      | XNFF3/8"-1"      | XNFF3/8"-1"      | XNFF3/8"-1"      | XNFF3/8"-1"      |
| * 16 | 半圓頭螺栓  | 2         | XNBH#10-32-3/8   | XNBH#10-32-3/8   | XNBH#10-32-3/8   | XNBH#10-32-3/8   | XNBH#10-32-3/8   | XNBH#10-32-3/8   | XNBH#10-32-3/8   | XNBH#10-32-3/8   | XNBH#10-32-3/8   |
| 17   | 保護蓋    | 1         | SRX8-L50-L13     | SRX8-L55-L13     | SRX8-L60-L13     | SRX8-L65-L13     | SRX8-L70-L13     | SRX8-L75-L13     | SRX8-L80-L13     | SRX8-L85-L13     | SRX8-L90-L13     |

\* 修理包零件






| 項次   | 品名       | 數量 | 品號                 |
|------|----------|----|--------------------|
| 1    | 本體       | 1  | SRX16-C01          |
| 2    | 主軸       | 1  | SRX16-C02          |
| 3    | 活塞       | 1  | SRX16-C03          |
| 4    | 尾蓋       | 1  | SRX16-C07          |
| * 5  | 背托環      | 1  | XGAS328            |
| * 6  | O形環      | 1  | XBAS328-90-NOK     |
| * 7  | O形環      | 1  | XABAS226-NOK       |
| * 8  | 背托環      | 1  | XAGAS226           |
| * 9  | 油封       | 1  | XEISI35            |
| 10   | 半月形推塊    | 2  | SRX16-C04          |
| 11   | 彈簧銷      | 1  | XA06-35            |
| 12   | 鋼珠       | 1  | XM1/4              |
| 13   | 內六角螺栓    | 1  | XNSETM8-16         |
| 14   | 1/8"PT塞頭 | 1  | XNPT1/8            |
| 15   | 旋轉軸座     | 1  | SMX10-A00-1-USA    |
| 16   | CAP螺栓    | 5  | XNCAPM6-20         |
| 17   | 出入口軸塊    | 1  | SMX10-A00-4-USA    |
| 18   | C形扣環     | 1  | XAS019             |
| * 19 | 背托環      | 4  | XGP020             |
| * 20 | O形環      | 3  | XP020-PU           |
| * 21 | O形環      | 2  | XP006-90-NOK       |
| * 22 | 背托環      | 2  | XGP006             |
| 23   | 接桿       | 1  | SMX10-A00-5-USA    |
| 24   | 內六角螺栓    | 1  | SETM06-12          |
| 25   | 彈簧       | 1  | XF0.8-D4.6-12L-6T= |
| 26   | 鋼珠       | 1  | XM3/16             |

\* 修理包

適用範圍：  
雙動六角中空液壓扳手

適用型號：SRX-16  
SRX-16L 連接體



|      |        | SRX-16 L70 |                       | SRX-16 L75            | SRX-16 L80            | SRX-16 L85            |
|------|--------|------------|-----------------------|-----------------------|-----------------------|-----------------------|
| 編號   | 品名     | 數量         | 品號                    | 品號                    | 品號                    | 品號                    |
| 1    | 兩側外板-右 | 1          | SRX16-L70-L1          | SRX16-L75-L1          | SRX16-L80-L1          | SRX16-L85-L1          |
| 2    | 兩側外板-左 | 1          | SRX16-L70-L2          | SRX16-L75-L2          | SRX16-L80-L2          | SRX16-L85-L2          |
| 3    | 搖座     | 1          | SRX16-L70-L3          | SRX16-L75-L3          | SRX16-L80-L3          | SRX16-L85-L3          |
| 4    | 棘輪     | 1          | SRX16-L70-L6          | SRX16-L75-L6          | SRX16-L80-L6          | SRX16-L85-L6          |
| 5    | 驅動齒    | 1          | SRX16-L70-L7          | SRX16-L75-L7          | SRX16-L80-L7          | SRX16-L85-L7          |
| 6    | 中隔塊    | 1          | SRX16-L70-L9          | SRX16-L75-L9          | SRX16-L80-L9          | SRX16-L85-L9          |
| 7    | 上隔塊    | 1          | SRX16-L70-L8          | SRX16-L75-L8          | SRX16-L80-L8          | SRX16-L85-L8          |
| 8    | 拉桿     | 1          | SRX16-L70-L4          | SRX16-L75-L4          | SRX16-L80-L4          | SRX16-L85-L4          |
| 9    | 彈簧     | 1          | XF1.2-D11.7-18.7L-5T= | XF1.2-D11.7-18.7L-5T= | XF1.2-D11.7-18.7L-5T= | XF1.2-D11.7-18.7L-5T= |
| 10   | 彈簧銷    | 1          | XA3/8-2 1/2           | XA3/8-2 1/2           | XA3/8-2 1/2           | XA3/8-2 1/2           |
| 11   | 反作用力彈簧 | 1          | SRX16-L5              | SRX16-L5              | SRX16-L5              | SRX16-L5              |
| 12   | 彈簧銷    | 1          | XA1/4-1 1/2           | XA1/4-1 1/2           | XA1/4-1 1/2           | XA1/4-1 1/2           |
| 13   | 下隔塊    | 1          | SRX16-L70-L10         | SRX16-L75-L10         | SRX16-L80-L10         | SRX16-L85-L10         |
| 14   | 銅襯     | 2          | SRX16-L70-L13         | SRX16-L75-L13         | SRX16-L80-L13         | SRX16-L85-L13         |
| * 15 | 下隔塊銷   | 2          | SRX16-L70-L11         | SRX16-L75-L11         | SRX16-L80-L11         | SRX16-L85-L11         |
| * 16 | 保護蓋    | 1          | SRX16-L70-L14         | SRX16-L75-L14         | SRX16-L80-L14         | SRX16-L85-L14         |
| 17   | 半圓頭螺栓  | 2          | XNHB1/4-3/8           | XNHB1/4-3/8           | XNHB1/4-3/8           | XNHB1/4-3/8           |
| 18   | 冊型螺栓   | 4          | XNF5/8-1 1/4          | XNF5/8-1 1/4          | XNF5/8-1 1/4          | XNF5/8-1 1/4          |
| 19   | CAP螺栓  | 4          | XNCAP3/8-1"           | XNCAP3/8-1"           | XNCAP3/8-1"           | XNCAP3/8-1"           |

\* 修理包零件

|      |        | SRX-16 L90 |                       | SRX-16 L95            | SRX-16 L100           | SRX-16 L105           |
|------|--------|------------|-----------------------|-----------------------|-----------------------|-----------------------|
| 編號   | 品名     | 數量         | 品號                    | 品號                    | 品號                    | 品號                    |
| 1    | 兩側外板-右 | 1          | SRX16-L90-L1          | SRX16-L95-L1          | SRX16-L100-L1         | SRX16-L105-L1         |
| 2    | 兩側外板-左 | 1          | SRX16-L90-L2          | SRX16-L95-L2          | SRX16-L100-L2         | SRX16-L105-L2         |
| 3    | 搖座     | 1          | SRX16-L90-L3          | SRX16-L95-L3          | SRX16-L100-L3         | SRX16-L105-L3         |
| 4    | 棘輪     | 1          | SRX16-L90-L6          | SRX16-L95-L6          | SRX16-L100-L6         | SRX16-L105-L6         |
| 5    | 驅動齒    | 1          | SRX16-L90-L7          | SRX16-L95-L7          | SRX16-L100-L7         | SRX16-L105-L7         |
| 6    | 中隔塊    | 1          | SRX16-L90-L9          | SRX16-L95-L9          | SRX16-L100-L9         | SRX16-L105-L9         |
| 7    | 上隔塊    | 1          | SRX16-L90-L8          | SRX16-L95-L8          | SRX16-L100-L8         | SRX16-L105-L8         |
| 8    | 拉桿     | 1          | SRX16-L90-L4          | SRX16-L95-L4          | SRX16-L100-L4         | SRX16-L105-L4         |
| 9    | 彈簧     | 1          | XF1.2-D11.7-18.7L-5T= | XF1.2-D11.7-18.7L-5T= | XF1.2-D11.7-18.7L-5T= | XF1.2-D11.7-18.7L-5T= |
| 10   | 彈簧銷    | 1          | XA3/8-2 1/2           | XA3/8-2 1/2           | XA3/8-2 1/2           | XA3/8-2 1/2           |
| 11   | 反作用力彈簧 | 1          | SRX16-L5              | SRX16-L5              | SRX16-L5              | SRX16-L5              |
| 12   | 彈簧銷    | 1          | XA1/4-1 1/2           | XA1/4-1 1/2           | XA1/4-1 1/2           | XA1/4-1 1/2           |
| 13   | 下隔塊    | 1          | SRX16-L90-L10         | SRX16-L95-L10         | SRX16-L100-L10        | SRX16-L105-L10        |
| * 14 | 銅襯     | 2          | SRX16-L90-L13         | SRX16-L95-L13         | SRX16-L100-L13        | SRX16-L105-L13        |
| * 15 | 下隔塊銷   | 2          | SRX16-L90-L11         | SRX16-L95-L11         | SRX16-L100-L11        | SRX16-L105-L11        |
| * 16 | 保護蓋    | 1          | SRX16-L90-L14         | SRX16-L95-L14         | SRX16-L100-L14        | SRX16-L105-L14        |
| 17   | 半圓頭螺栓  | 2          | XNHB1/4-3/8           | XNHB1/4-3/8           | XNHB1/4-3/8           | XNHB1/4-3/8           |
| 18   | 冊型螺栓   | 4          | XNF5/8-1 1/4          | XNF5/8-1 1/4          | XNF5/8-1 1/4          | XNF5/8-1 1/4          |
| 19   | CAP螺栓  | 4          | XNCAP3/8-1"           | XNCAP3/8-1"           | XNCAP3/8-1"           | XNCAP3/8-1"           |

\* 修理包零件


|      |        | SRX-16 L110 |                       | SRX-16 L115           |
|------|--------|-------------|-----------------------|-----------------------|
| 編號   | 品名     | 數量          | 品號                    | 品號                    |
| 1    | 兩側外板-右 | 1           | SRX16-L110-L1         | SRX16-L115-L1         |
| 2    | 兩側外板-左 | 1           | SRX16-L110-L2         | SRX16-L115-L2         |
| 3    | 搖座     | 1           | SRX16-L110-L3         | SRX16-L115-L3         |
| 4    | 棘輪     | 1           | SRX16-L110-L6         | SRX16-L115-L6         |
| 5    | 驅動齒    | 1           | SRX16-L110-L7         | SRX16-L115-L7         |
| 6    | 中隔塊    | 1           | SRX16-L110-L9         | SRX16-L115-L9         |
| 7    | 上隔塊    | 1           | SRX16-L110-L8         | SRX16-L115-L8         |
| 8    | 拉桿     | 1           | SRX16-L110-L4         | SRX16-L115-L4         |
| 9    | 彈簧     | 1           | XF1.2-D11.7-18.7L-5T= | XF1.2-D11.7-18.7L-5T= |
| 10   | 彈簧銷    | 1           | XA3/8-2 1/2           | XA3/8-2 1/2           |
| 11   | 反作用力彈簧 | 1           | SRX16-L5              | SRX16-L5              |
| 12   | 彈簧銷    | 1           | XA1/4-1 1/2           | XA1/4-1 1/2           |
| 13   | 下隔塊    | 1           | SRX16-L110-L10        | SRX16-L115-L10        |
| * 14 | 銅襯     | 2           | SRX16-L110-L13        | SRX16-L115-L13        |
| * 15 | 下隔塊銷   | 2           | SRX16-L110-L11        | SRX16-L115-L11        |
| * 16 | 保護蓋    | 1           | SRX16-L110-L14        | SRX16-L115-L14        |
| 17   | 半圓頭螺栓  | 2           | XNHB1/4-3/8           | XNHB1/4-3/8           |
| 18   | 冊型螺栓   | 4           | XNF5/8-1 1/4          | XNF5/8-1 1/4          |
| 19   | CAP螺栓  | 4           | XNCAP3/8-1"           | XNCAP3/8-1"           |

\* 修理包零件



巨輪興股份有限公司






| 編號   | 品名     | 數量 | 品號                 |
|------|--------|----|--------------------|
| 1    | 本體     | 1  | SRX32-C01          |
| 2    | 主軸     | 1  | SRX32-C02          |
| * 3  | 背托環    | 2  | XGAS333            |
| * 4  | O形環    | 2  | XBAS333            |
| 5    | 尾蓋     | 1  | SRX32-C07          |
| * 6  | O形環    | 1  | XBAS326            |
| * 7  | 背托環    | 1  | XGAS326            |
| * 8  | 半月形推塊  | 2  | SRX32-C06          |
| 9    | 彈簧銷    | 1  | XA08-45            |
| 10   | 接桿     | 1  | SMX10-A00-5-USA    |
| 11   | 旋轉軸座   | 1  | SMX10-A00-1-USA    |
| 12   | 螺栓     | 5  | XNCAPM6-20         |
| * 13 | O形環    | 3  | XBP20-PU           |
| * 14 | 背托環    | 4  | XGP20              |
| 15   | 出入口軸塊組 | 1  | SMX10-A00-4-USA    |
| 16   | C形扣環   | 1  | XAS019             |
| 17   | 內六角螺栓  | 1  | SETM06-12          |
| 18   | 彈簧     | 1  | XF0.8-D4.6-12L-6T= |
| 19   | 鋼珠     | 1  | XM3/16             |
| * 20 | 背托環    | 4  | XGAS015            |
| * 21 | O形環    | 4  | XBPAS015-PU        |

\* 修理包

適用範圍：  
雙動六角中空液壓扳手

適用型號：SRX-32  
SRX-32L 連接體



| SRX-32 L80 |        |    | SRX-32 L85        |                   |                   | SRX-32 L90 |    |    |
|------------|--------|----|-------------------|-------------------|-------------------|------------|----|----|
| 編碼         | 品名     | 數量 | 品號                | 品號                | 品號                | 品號         | 品號 | 品號 |
| 1          | 兩側外板-右 | 1  | SRX32-L80-L1      | SRX32-L85-L1      | SRX32-L90-L1      |            |    |    |
| 2          | 兩側外板-左 | 1  | SRX32-L80-L2      | SRX32-L85-L2      | SRX32-L90-L2      |            |    |    |
| 3          | 銅襯     | 2  | SRX32-L80-L12     | SRX32-L85-L12     | SRX32-L90-L12     |            |    |    |
| 4          | 搖座     | 1  | SRX32-L80-L3      | SRX32-L85-L3      | SRX32-L90-L3      |            |    |    |
| 5          | 棘輪     | 1  | SRX32-L80-L6      | SRX32-L85-L6      | SRX32-L90-L6      |            |    |    |
| 6          | 驅動齒    | 1  | SRX32-L80-L7      | SRX32-L85-L7      | SRX32-L90-L7      |            |    |    |
| 7          | 驅動齒彈簧  | 2  | SRX32-L80-L14     | SRX32-L85-L14     | SRX32-L90-L14     |            |    |    |
| 8          | 反作用彈簧  | 1  | SRX32-L80-L5      | SRX32-L85-L5      | SRX32-L90-L5      |            |    |    |
| 9          | 拉桿     | 1  | SRX32-L80-L4      | SRX32-L85-L4      | SRX32-L90-L4      |            |    |    |
| 10         | 彈簧鎖    | 1  | XA2/8x1-1/4L      | XA2/8x1-1/4L      | XA2/8x1-1/4L      |            |    |    |
| 11         | 上隔塊    | 1  | SRX32-L80-L8      | SRX32-L85-L8      | SRX32-L90-L8      |            |    |    |
| 12         | 下隔塊    | 1  | SRX32-L80-L10     | SRX32-L85-L10     | SRX32-L90-L10     |            |    |    |
| 13         | 定位鎖    | 2  | SRX32-L80-L11     | SRX32-L85-L11     | SRX32-L90-L11     |            |    |    |
| * 14       | CAP螺栓  | 4  | XNCAP3/8-10x1L    | XNCAP3/8-10x1L    | XNCAP3/8-10x1L    |            |    |    |
| * 15       | 皿型螺栓   | 4  | XNF5/8-11x7/8L    | XNF5/8-11x7/8L    | XNF5/8-11x7/8L    |            |    |    |
| * 16       | 半圓頭螺栓  | 2  | XNBH1/4-20x11/32L | XNBH1/4-20x11/32L | XNBH1/4-20x11/32L |            |    |    |
| 17         | 保護蓋    | 1  | SRX32-L80-L13     | SRX32-L85-L13     | SRX32-L90-L13     |            |    |    |


\* 修理包零件

| SRX-32 L95 |        |    | SRX-32 L100       |                   |                   | SRX-32 L105 |    |    |
|------------|--------|----|-------------------|-------------------|-------------------|-------------|----|----|
| 編碼         | 品名     | 數量 | 品號                | 品號                | 品號                | 品號          | 品號 | 品號 |
| 1          | 兩側外板-右 | 1  | SRX32-L95-L1      | SRX32-L100-L1     | SRX32-L105-L1     |             |    |    |
| 2          | 兩側外板-左 | 1  | SRX32-L95-L2      | SRX32-L100-L2     | SRX32-L105-L2     |             |    |    |
| 3          | 銅襯     | 2  | SRX32-L95-L12     | SRX32-L100-L12    | SRX32-L105-L12    |             |    |    |
| 4          | 搖座     | 1  | SRX32-L95-L3      | SRX32-L100-L3     | SRX32-L105-L3     |             |    |    |
| 5          | 棘輪     | 1  | SRX32-L95-L6      | SRX32-L100-L6     | SRX32-L105-L6     |             |    |    |
| 6          | 驅動齒    | 1  | SRX32-L95-L7      | SRX32-L100-L7     | SRX32-L105-L7     |             |    |    |
| 7          | 驅動齒彈簧  | 2  | SRX32-L95-L14     | SRX32-L100-L14    | SRX32-L105-L14    |             |    |    |
| 8          | 反作用彈簧  | 1  | SRX32-L95-L5      | SRX32-L100-L5     | SRX32-L105-L5     |             |    |    |
| 9          | 拉桿     | 1  | SRX32-L95-L4      | SRX32-L100-L4     | SRX32-L105-L4     |             |    |    |
| 10         | 彈簧鎖    | 1  | XA2/8x1-1/4L      | XA2/8x1-1/4L      | XA2/8x1-1/4L      |             |    |    |
| 11         | 上隔塊    | 1  | SRX32-L95-L8      | SRX32-L100-L8     | SRX32-L105-L8     |             |    |    |
| 12         | 下隔塊    | 1  | SRX32-L95-L10     | SRX32-L100-L10    | SRX32-L105-L10    |             |    |    |
| 13         | 定位鎖    | 2  | SRX32-L95-L11     | SRX32-L100-L11    | SRX32-L105-L11    |             |    |    |
| * 14       | CAP螺栓  | 4  | XNCAP3/8-10x1L    | XNCAP3/8-10x1L    | XNCAP3/8-10x1L    |             |    |    |
| * 15       | 皿型螺栓   | 4  | XNF5/8-11x7/8L    | XNF5/8-11x7/8L    | XNF5/8-11x7/8L    |             |    |    |
| * 16       | 半圓頭螺栓  | 2  | XNBH1/4-20x11/32L | XNBH1/4-20x11/32L | XNBH1/4-20x11/32L |             |    |    |
| 17         | 保護蓋    | 1  | SRX32-L95-L13     | SRX32-L100-L13    | SRX32-L105-L13    |             |    |    |

\* 修理包零件


| SRX-32 L110 |        |    | SRX-32 L115       |                   |                   | SRX-32 L117       |                   |                   | SRX-32 L120       |                   |                   | SRX-32 L125       |                   |    | SRX-32 L130 |    |    | SRX-32 L135 |    |    | SRX-32 L140 |    |    | SRX-32 L145 |    |    | SRX-32 L150 |    |    | SRX-32 L155 |  |  |
|-------------|--------|----|-------------------|-------------------|-------------------|-------------------|-------------------|-------------------|-------------------|-------------------|-------------------|-------------------|-------------------|----|-------------|----|----|-------------|----|----|-------------|----|----|-------------|----|----|-------------|----|----|-------------|--|--|
| 編號          | 品名     | 數量 | 品號                | 品號                | 品號                | 品號                | 品號                | 品號                | 品號                | 品號                | 品號                | 品號                | 品號                | 品號 | 品號          | 品號 | 品號 | 品號          | 品號 | 品號 | 品號          | 品號 | 品號 | 品號          | 品號 | 品號 | 品號          | 品號 | 品號 | 品號          |  |  |
| 1           | 兩側外板-右 | 1  | SRX32-L110-L1     | SRX32-L115-L1     | SRX32-L117-L1     | SRX32-L120-L1     | SRX32-L125-L1     | SRX32-L130-L1     | SRX32-L135-L1     | SRX32-L140-L1     | SRX32-L145-L1     | SRX32-L150-L1     | SRX32-L155-L1     |    |             |    |    |             |    |    |             |    |    |             |    |    |             |    |    |             |  |  |
| 2           | 兩側外板-左 | 1  | SRX32-L110-L2     | SRX32-L115-L2     | SRX32-L117-L2     | SRX32-L120-L2     | SRX32-L125-L2     | SRX32-L130-L2     | SRX32-L135-L2     | SRX32-L140-L2     | SRX32-L145-L2     | SRX32-L150-L2     | SRX32-L155-L2     |    |             |    |    |             |    |    |             |    |    |             |    |    |             |    |    |             |  |  |
| 3           | 銅襯     | 2  | SRX32-L110-L12    | SRX32-L115-L12    | SRX32-L117-L12    | SRX32-L120-L12    | SRX32-L125-L12    | SRX32-L130-L12    | SRX32-L135-L12    | SRX32-L140-L12    | SRX32-L145-L12    | SRX32-L150-L12    | SRX32-L155-L12    |    |             |    |    |             |    |    |             |    |    |             |    |    |             |    |    |             |  |  |
| 4           | 搖座     | 1  | SRX32-L110-L3     | SRX32-L115-L3     | SRX32-L117-L3     | SRX32-L120-L3     | SRX32-L125-L3     | SRX32-L130-L3     | SRX32-L135-L3     | SRX32-L140-L3     | SRX32-L145-L3     | SRX32-L150-L3     | SRX32-L155-L3     |    |             |    |    |             |    |    |             |    |    |             |    |    |             |    |    |             |  |  |
| 5           | 棘輪     | 1  | SRX32-L110-L6     | SRX32-L115-L6     | SRX32-L117-L6     | SRX32-L120-L6     | SRX32-L125-L6     | SRX32-L130-L6     | SRX32-L135-L6     | SRX32-L140-L6     | SRX32-L145-L6     | SRX32-L150-L6     | SRX32-L155-L6     |    |             |    |    |             |    |    |             |    |    |             |    |    |             |    |    |             |  |  |
| 6           | 驅動齒    | 1  | SRX32-L110-L7     | SRX32-L115-L7     | SRX32-L117-L7     | SRX32-L120-L7     | SRX32-L125-L7     | SRX32-L130-L7     | SRX32-L135-L7     | SRX32-L140-L7     | SRX32-L145-L7     | SRX32-L150-L7     | SRX32-L155-L7     |    |             |    |    |             |    |    |             |    |    |             |    |    |             |    |    |             |  |  |
| 7           | 驅動齒彈簧  | 1  | SRX32-L110-L14    | SRX32-L115-L14    | SRX32-L117-L14    | SRX32-L120-L14    | SRX32-L125-L14    | SRX32-L130-L14    | SRX32-L135-L14    | SRX32-L140-L14    | SRX32-L145-L14    | SRX32-L150-L14    | SRX32-L155-L14    |    |             |    |    |             |    |    |             |    |    |             |    |    |             |    |    |             |  |  |
| 8           | 反作用彈簧  | 1  | SRX32-L110-L5     | SRX32-L115-L5     | SRX32-L117-L5     | SRX32-L120-L5     | SRX32-L125-L5     | SRX32-L130-L5     | SRX32-L135-L5     | SRX32-L140-L5     | SRX32-L145-L5     | SRX32-L150-L5     | SRX32-L155-L5     |    |             |    |    |             |    |    |             |    |    |             |    |    |             |    |    |             |  |  |
| 9           | 拉桿     | 1  | SRX32-L110-L4     | SRX32-L115-L4     | SRX32-L117-L4     | SRX32-L120-L4     | SRX32-L125-L4     | SRX32-L130-L4     | SRX32-L135-L4     | SRX32-L140-L4     | SRX32-L145-L4     | SRX32-L150-L4     | SRX32-L155-L4     |    |             |    |    |             |    |    |             |    |    |             |    |    |             |    |    |             |  |  |
| 10          | 彈簧鎖    | 1  | XA2/8x1-1/4L      | XA2/8x1-1/4L      | XA2/8x1-1/4L      | XA2/8x1-1/4L      | XA2/8x1-1/4L      | XA2/8x1-1/4L      | XA2/8x1-1/4L      | XA2/8x1-1/4L      | XA2/8x1-1/4L      | XA2/8x1-1/4L      | XA2/8x1-1/4L      |    |             |    |    |             |    |    |             |    |    |             |    |    |             |    |    |             |  |  |
| 11          | 上隔塊    | 1  | SRX32-L110-L8     | SRX32-L115-L8     | SRX32-L117-L8     | SRX32-L120-L8     | SRX32-L125-L8     | SRX32-L130-L8     | SRX32-L135-L8     | SRX32-L140-L8     | SRX32-L145-L8     | SRX32-L150-L8     | SRX32-L155-L8     |    |             |    |    |             |    |    |             |    |    |             |    |    |             |    |    |             |  |  |
| 12          | 下隔塊    | 1  | SRX32-L110-L10    | SRX32-L115-L10    | SRX32-L117-L10    | SRX32-L120-L10    | SRX32-L125-L10    | SRX32-L130-L10    | SRX32-L135-L10    | SRX32-L140-L10    | SRX32-L145-L10    | SRX32-L150-L10    | SRX32-L155-L10    |    |             |    |    |             |    |    |             |    |    |             |    |    |             |    |    |             |  |  |
| 13          | 定位鎖    | 2  | SRX32-L110-L11    | SRX32-L115-L11    | SRX32-L117-L11    | SRX32-L120-L11    | SRX32-L125-L11    | SRX32-L130-L11    | SRX32-L135-L11    | SRX32-L140-L11    | SRX32-L145-L11    | SRX32-L150-L11    | SRX32-L155-L11    |    |             |    |    |             |    |    |             |    |    |             |    |    |             |    |    |             |  |  |
| * 14        | CAP螺栓  | 4  | XNCAP3/8-10x1L    | XNCAP3/8-10x1L    | XNCAP3/8-10x1L    | XNCAP3/8-10x1L    | XNCAP3/8-10x1L    | XNCAP3/8-10x1L    | XNCAP3/8-10x1L    | XNCAP3/8-10x1L    | XNCAP3/8-10x1L    | XNCAP3/8-10x1L    | XNCAP3/8-10x1L    |    |             |    |    |             |    |    |             |    |    |             |    |    |             |    |    |             |  |  |
| * 15        | 皿型螺栓   | 4  | XNF5/8-11x7/8L    | XNF5/8-11x7/8L    | XNF5/8-11x7/8L    | XNF5/8-11x7/8L    | XNF5/8-11x7/8L    | XNF5/8-11x7/8L    | XNF5/8-11x7/8L    | XNF5/8-11x7/8L    | XNF5/8-11x7/8L    | XNF5/8-11x7/8L    | XNF5/8-11x7/8L    |    |             |    |    |             |    |    |             |    |    |             |    |    |             |    |    |             |  |  |
| * 16        | 半圓頭螺栓  | 2  | XNBH1/4-20x11/32L | XNBH1/4-20x11/32L | XNBH1/4-20x11/32L | XNBH1/4-20x11/32L | XNBH1/4-20x11/32L | XNBH1/4-20x11/32L | XNBH1/4-20x11/32L | XNBH1/4-20x11/32L | XNBH1/4-20x11/32L | XNBH1/4-20x11/32L | XNBH1/4-20x11/32L |    |             |    |    |             |    |    |             |    |    |             |    |    |             |    |    |             |  |  |
| 17          | 保護蓋    | 1  | SRX32-L110-L13    | SRX32-L115-L13    | SRX32-L117-L13    | SRX32-L120-L13    | SRX32-L125-L13    | SRX32-L130-L13    | SRX32-L135-L13    | SRX32-L140-L13    | SRX32-L145-L13    | SRX32-L150-L13    | SRX32-L155-L13    |    |             |    |    |             |    |    |             |    |    |             |    |    |             |    |    |             |  |  |

\* 修理包零件





| Item | Part               | Q'ty | Part Number    |
|------|--------------------|------|----------------|
| 1    | Housing assembly   | 1    | SRX2-C01       |
| 2    | plunger            | 1    | SRX2-C02       |
| 3    | end cap            | 1    | SRX2-C03       |
| * 4  | back-up ring       | 1    | XG3023         |
| * 5  | O-ring             | 1    | XBAS119-90-NOK |
| * 6  | O-ring             | 1    | XBS025         |
| * 7  | back-up ring       | 1    | XG025-028-1.25 |
| * 8  | O-ring             | 1    | XBP016-90-NOK  |
| * 9  | back-up ring       | 1    | XBP016         |
| 10   | half-moon pusher   | 2    | SRX2-C06       |
| 11   | spring plug        | 1    | XA3-16         |
| 12   | bolt               | 1    | SRX2-C12       |
| 13   | link retaining pin | 1    | SRX2-C09       |
| 14   | plug               | 2    | XNPT1/16       |
| 15   | plug               | 1    | SRX2-C04       |
| * 16 | O-ring             | 3    | XBP005-90-NOK  |
| * 17 | back-up ring       | 2    | XGP005         |
| 18   | swivel assembly    | 1    | SRX2-C05       |
| 19   | bolt               | 4    | XNCAPM05-15    |
| * 20 | O-ring             | 3    | XBP018-PU      |
| * 21 | back-up ring       | 4    | XHP018         |
| 22   | in/ out base       | 1    | SMX3-A00       |
| 23   | C type ring        | 1    | XAS015         |
| * 24 | back-up ring       | 4    | XGAS014        |
| * 25 | O-ring             | 4    | XBPAS014-PU    |

\* repair kit



|      |                   |      | SRX-2 L30           | SRX-2 L32           | SRX-2 L36           | SRX-2 L41           | SRX-2 L46           | SRX-2 L50           | SRX-2 L55           | SRX-2 L60           |
|------|-------------------|------|---------------------|---------------------|---------------------|---------------------|---------------------|---------------------|---------------------|---------------------|
| Item | product           | Q'ty | Part No.            | Part No.            | Part No.            | Part No.            | Part No.            | Part No.            | Part No.            | Part No.            |
| 1    | side plate-R      | 1    | SRX2-L30-L1         | SRX2-L32-L1         | SRX2-L36-L1         | SRX2-L41-L1         | SRX2-L46-L1         | SRX2-L50-L1         | SRX2-L55-L1         | SRX2-L60-L1         |
| 2    | side plate-L      | 1    | SRX2-L30-L2         | SRX2-L32-L2         | SRX2-L36-L2         | SRX2-L41-L2         | SRX2-L46-L2         | SRX2-L50-L2         | SRX2-L55-L2         | SRX2-L60-L2         |
| 3    | copper ring       | 2    | SRX2-L30-L12        | SRX2-L32-L12        | SRX2-L36-L12        | SRX2-L41-L12        | SRX2-L46-L12        | SRX2-L50-L12        | SRX2-L55-L12        | SRX2-L60-L12        |
| 4    | bronze sleeve     | 1    | SRX2-L30-L3         | SRX2-L32-L3         | SRX2-L36-L3         | SRX2-L41-L3         | SRX2-L46-L3         | SRX2-L50-L3         | SRX2-L55-L3         | SRX2-L60-L3         |
| 5    | reachet           | 1    | SRX2-L30-L6         | SRX2-L32-L6         | SRX2-L36-L6         | SRX2-L41-L6         | SRX2-L46-L6         | SRX2-L50-L6         | SRX2-L55-L6         | SRX2-L60-L6         |
| 6    | drive pawl        | 1    | SRX2-L30-L7         | SRX2-L32-L7         | SRX2-L36-L7         | SRX2-L41-L7         | SRX2-L46-L7         | SRX2-L50-L7         | SRX2-L55-L7         | SRX2-L60-L7         |
| 7    | drive pawl spring | 1    | XF0.6-D4.5-13.5L-8T | XF0.6-D4.5-13.5L-8T | XF0.6-D4.5-13.5L-8T | XF0.6-D4.5-13.5L-8T | XF0.6-D4.5-13.5L-8T | XF0.6-D4.5-13.5L-8T | XF0.6-D4.5-13.5L-8T | XF0.6-D4.5-13.5L-8T |
| 8    | reaction spring   | 1    | XF-SRX2             | XFSRX2              | XFSRX2              | XFSRX2              | XFSRX2              | XFSRX2              | XFSRX2              | XFSRX2              |
| 9    | slide hook pin    | 1    | SRX2-L30-L4         | SRX2-L4             | SRX2-L4             | SRX2-L4             | SRX2-L4             | SRX2-L4             | SRX2-L4             | SRX2-L4             |
| 10   | roll pin          | 1    | XA1/8x5/8L          | XA3-16              | XA3-16              | XA3-16              | XA3-16              | XA3-16              | XA3-16              | XA3-16              |
| 11   | slide upper       | 1    | SRX2-L30-L8         | SRX2-L30-L8         | SRX2-L30-L8         | SRX2-L30-L8         | SRX2-L30-L8         | SRX2-L50-L8         | SRX2-L50-L8         | SRX2-L50-L8         |
| 12   | slide bottom      | 1    | SRX2-L30-L10        | SRX2-L10            | SRX2-L10            | SRX2-L10            | SRX2-L10            | SRX2-L10            | SRX2-L10            | SRX2-L10            |
| 13   | fixed pin         | 2    | SRX2-L30-L11        | SRX2-L11            | SRX2-L11            | SRX2-L11            | SRX2-L11            | SRX2-L11            | SRX2-L11            | SRX2-L11            |
| * 14 | CAP bolt          | 4    | XNCAP#8-32x3/8L     | XNCAP#8-32UNC-3/8"  | XNCAP#8-32UNC-3/8"  | XNCAP#8-32UNC-3/8"  | XNCAP#8-32UNC-3/8"  | XNCAP#8-32UNC-3/8"  | XNCAP#8-32UNC-3/8"  | XNCAP#8-32UNC-3/8"  |
| * 15 | countersink       | 4    | XNF1/4"-20x5/8L     | XNF1/4"-20UNC-1/2"  | XNF1/4"-20UNC-1/2"  | XNF1/4"-20UNC-1/2"  | XNF1/4"-20UNC-1/2"  | XNF1/4"-20UNC-1/2"  | XNF1/4"-20UNC-1/2"  | XNF1/4"-20UNC-1/2"  |
| * 16 | oval head bolt    | 2    | XNBH#8-32x1/4L      | XNBH#8-32UNC-1/4L"  | XNBH#8-32UNC-1/4L"  | XNBH#8-32UNC-1/4L"  | XNBH#8-32UNC-1/4L"  | XNBH#8-32UNC-1/4L"  | XNBH#8-32UNC-1/4L"  | XNBH#8-32UNC-1/4L"  |
| 17   | shroud            | 1    | SRX2-L30-L13        | SRX2-L13            | SRX2-L13            | SRX2-L13            | SRX2-L13            | SRX2-L13            | SRX2-L13            | SRX2-L13            |

\* repair kit




| Item | Part                 | Q'ty | Part Number       |
|------|----------------------|------|-------------------|
| 1    | Housing assembly     | 1    | SRX4-C01          |
| 2    | plunger              | 1    | SRX4-C02          |
| 3    | end cap              | 1    | SRX4-C03          |
| * 4  | back-up ring         | 2    | XGP030            |
| * 5  | O-ring               | 2    | XBP030-90-NOK     |
| * 6  | O-ring               | 1    | XBP022-90-NOK     |
| * 7  | back-up ring         | 1    | XGP022            |
| 8    | half-moon pusher     | 2    | SRX4-C06          |
| 9    | plug                 | 2    | XNPT1/16          |
| 10   | plug                 | 1    | SRX2-C04          |
| * 11 | back-up ring         | 2    | XGP005            |
| * 12 | O-ring               | 2    | XBP005            |
| * 13 | O-ring               | 1    | XBP004            |
| 14   | swivel assembly      | 1    | SRX2-C05          |
| 15   | bolt                 | 4    | XNCAPM05-15       |
| * 16 | back-up ring         | 4    | XHP018            |
| * 17 | O-ring               | 3    | XBP018-PU         |
| 18   | in/ out base         | 1    | SMX3-A00-4        |
| 19   | C type ring          | 1    | XAS015            |
| * 20 | back-up ring         | 4    | XGAS014           |
| * 21 | O-ring               | 4    | XBAS014           |
| 22   | inlet/ outlet-male   | 1    | SMX3-A00-2        |
| 23   | inlet/ outlet-female | 1    | SMX3-A00-3        |
| 24   | level axle           | 1    | SRX4-C09          |
| 25   | bolt                 | 1    | SRX4-C12          |
| 26   | spring               | 1    | XF0.7-D4.3-5.2-3T |
| 27   | steel ball           | 1    | XM3/16            |
| 28   | spring plug          | 1    | XA04-20           |

\* repair kit




Instructions for:  
Double-Acting, Hexgon Cassette Torque Wrench

Model : SRX-4  
SRX-4L Link



|      |                   |      | SRX-4 L41        | SRX-4 L46        | SRX-4 L50        | SRX-4 L55        | SRX-4 L60        | SRX-4 L65        | SRX-4 L70        | SRX-4 L75        | SRX-4 L80        |
|------|-------------------|------|------------------|------------------|------------------|------------------|------------------|------------------|------------------|------------------|------------------|
| Item | product           | Q'ty | Part No.         | Part No.         | Part No.         | Part No.         | Part No.         | Part No.         | Part No.         | Part No.         | Part No.         |
| 1    | side plate-R      | 1    | SRX4-L41-L1      | SRX4-L46-L1      | SRX4-L50-L1      | SRX4-L55-L1      | SRX4-L60-L1      | SRX4-L65-L1      | SRX4-L70-L1      | SRX4-L75-L1      | SRX4-L80-L1      |
| 2    | side plate-L      | 1    | SRX4-L41-L2      | SRX4-L46-L2      | SRX4-L50-L2      | SRX4-L55-L2      | SRX4-L60-L2      | SRX4-L65-L2      | SRX4-L70-L2      | SRX4-L75-L2      | SRX4-L80-L2      |
| 3    | copper ring       | 2    | SRX4-L41-L12     | SRX4-L46-L12     | SRX4-L50-L12     | SRX4-L55-L12     | SRX4-L60-L12     | SRX4-L65-L12     | SRX4-L70-L12     | SRX4-L75-L12     | SRX4-L80-L12     |
| 4    | bronze sleeve     | 1    | SRX4-L41-L3      | SRX4-L46-L3      | SRX4-L50-L3      | SRX4-L55-L3      | SRX4-L60-L3      | SRX4-L65-L3      | SRX4-L70-L3      | SRX4-L75-L3      | SRX4-L80-L3      |
| 5    | reatchet          | 1    | SRX4-L41-L6      | SRX4-L46-L6      | SRX4-L50-L6      | SRX4-L55-L6      | SRX4-L60-L6      | SRX4-L65-L6      | SRX4-L70-L6      | SRX4-L75-L6      | SRX4-L80-L6      |
| 6    | drive pawl        | 1    | SRX4-L41-L7      | SRX4-L46-L7      | SRX4-L50-L7      | SRX4-L55-L7      | SRX4-L60-L7      | SRX4-L65-L7      | SRX4-L70-L7      | SRX4-L75-L7      | SRX4-L80-L7      |
| 7    | drive pawl spring | 1    | XF0.8-D6.2-15-7T | XF0.8-D6.2-15-7T | XF0.8-D6.2-15-7T | XF0.8-D6.2-15-7T | XF0.8-D6.2-15-7T | XF0.8-D6.2-15-7T | XF0.8-D6.2-15-7T | XF0.8-D6.2-15-7T | XF0.8-D6.2-15-7T |
| 8    | reaction spring   | 1    | XF-SRX4          | XF-SRX4          | XF-SRX4          | XF-SRX4          | XF-SRX4          | XF-SRX4          | XF-SRX4          | XF-SRX4          | XF-SRX4          |
| 9    | slide hook pin    | 1    | SRX4-L41-L4      | SRX4-L41-L4      | SRX4-L41-L4      | SRX4-L41-L4      | SRX4-L41-L4      | SRX4-L41-L4      | SRX4-L41-L4      | SRX4-L41-L4      | SRX4-L41-L4      |
| 10   | roll pin          | 1    | XA1/8x7/8L       | XA1/8x7/8L       | XA1/8x7/8L       | XA1/8x7/8L       | XA1/8x7/8L       | XA1/8x7/8L       | XA1/8x7/8L       | XA1/8x7/8L       | XA1/8x7/8L       |
| 11   | slide upper       | 1    | SRX4-L41-L8      | SRX4-L41-L8      | SRX4-L55-L8      | SRX4-L55-L8      | SRX4-L55-L8      | SRX4-L55-L8      | SRX4-L70-L8      | SRX4-L70-L8      | SRX4-L70-L8      |
| 12   | slide bottom      | 1    | SRX4-L41-L10     | SRX4-L41-L10     | SRX4-L41-L10     | SRX4-L41-L10     | SRX4-L41-L10-1   | SRX4-L41-L10-1   | SRX4-L41-L10-1   | SRX4-L41-L10-1   | SRX4-L41-L10-1   |
| 13   | fixed pin         | 2    | SRX4-L41-L11     | SRX4-L41-L11     | SRX4-L41-L11     | SRX4-L41-L11     | SRX4-L41-L11     | SRX4-L41-L11     | SRX4-L41-L11     | SRX4-L41-L11     | SRX4-L41-L11     |
| * 14 | CAP bolt          | 4    | XNCAP#10-32x1/2L | XNCAP#10-32x1/2L | XNCAP#10-32x1/2L | XNCAP#10-32x1/2L | XNCAP#10-32x1/2L | XNCAP#10-32x1/2L | XNCAP#10-32x1/2L | XNCAP#10-32x1/2L | XNCAP#10-32x1/2L |
| * 15 | countersink       | 4    | XNF5/16-18x3/4L  | XNF5/16-18x3/4L  | XNF5/16-18x3/4L  | XNF5/16-18x3/4L  | XNF5/16-18x3/4L  | XNF5/16-18x3/4L  | XNF5/16-18x3/4L  | XNF5/16-18x3/4L  | XNF5/16-18x3/4L  |
| * 16 | oval head bolt    | 2    | XNBH#8-32x1/4L   | XNBH#8-32x1/4L   | XNBH#8-32x1/4L   | XNBH#8-32x1/4L   | XNBH#8-32x1/4L   | XNBH#8-32x1/4L   | XNBH#8-32x1/4L   | XNBH#8-32x1/4L   | XNBH#8-32x1/4L   |
| 17   | shroud            | 1    | SRX4-L41-L13     | SRX4-L41-L13     | SRX4-L41-L13     | SRX4-L41-L13     | SRX4-L41-L13     | SRX4-L41-L13     | SRX4-L41-L13     | SRX4-L41-L13     | SRX4-L41-L13     |

\* repair kit




| Item | Part                 | Q'ty | Part Number       |
|------|----------------------|------|-------------------|
| 1    | Housing assembly     | 1    | SRX8-C01          |
| 2    | plunger              | 1    | SRX8-C02          |
| 3    | end cap              | 1    | SRX8-C03          |
| * 4  | O-ring               | 2    | XBP040-90-NOK     |
| * 5  | back-up ring         | 3    | XGP040            |
| 6    | half-moon pusher     | 2    | SRX8-C06          |
| 7    | spring plug          | 1    | XA05-28           |
| * 8  | back-up ring         | 1    | XGP028            |
| * 9  | O-ring               | 1    | XBP028-90-NOK     |
| 10   | plug                 | 1    | SRX2-C04          |
| * 11 | O-ring               | 2    | XBP005            |
| * 12 | back-up ring         | 2    | XGP005            |
| * 13 | O-ring               | 1    | XBP004            |
| 14   | swivel assembly      | 1    | SRX2-C05          |
| 15   | bolt                 | 4    | XNCAPM05-15       |
| * 16 | O-ring               | 3    | XBP018-PU         |
| * 17 | back-up ring         | 4    | XHP018            |
| 18   | inlet/ outlet-male   | 1    | SMX3-A00-2        |
| 19   | inlet/ outlet-female | 1    | SMX3-A00-3        |
| 20   | in/ out base         | 1    | SMX3-A00-4        |
| 21   | C type ring          | 1    | XAS015            |
| * 22 | back-up ring         | 4    | XGAS014           |
| * 23 | O-ring               | 4    | XBAS014           |
| 24   | bolt                 | 1    | XNSETM06-12       |
| 25   | spring               | 1    | XF0.7-D4.3-5.2-3T |
| 26   | steel ball           | 1    | XM3/16            |

\* repair kit

Instructions for:  
Double-Acting, Hexgon Cassette Torque Wrench

Model : SRX-8  
SRX-8L Link



|      |                   |      | SRX-8 L95        | SRX-8 L100       | SRX-8 L105       |
|------|-------------------|------|------------------|------------------|------------------|
| Item | product           | Q'ty | Part No.         | Part No.         | Part No.         |
| 1    | side plate-R      | 1    | SRX8-L95-L1-1    | SRX8-L100-L1-1   | SRX8-L105-L1-1   |
| 2    | side plate-L      | 1    | SRX8-L95-L1-2    | SRX8-L100-L1-2   | SRX8-L105-L1-2   |
| 3    | copper ring       | 2    | SRX8-L95-L12     | SRX8-L100-L12    | SRX8-L105-L12    |
| 4    | bronze sleeve     | 1    | SRX8-L95-L3      | SRX8-L100-L3     | SRX8-L105-L3     |
| 5    | reatchet          | 1    | SRX8-L95-L6      | SRX8-L100-L6     | SRX8-L105-L6     |
| 6    | drive pawl        | 1    | SRX8-L95-L7      | SRX8-L100-L7     | SRX8-L105-L7     |
| 7    | drive pawl spring | 1    | XF0.8-D6.2-10-8T | XF0.8-D6.2-10-8T | XF0.8-D6.2-10-8T |
| 8    | reaction spring   | 1    | XF-SRX8          | XF-SRX8          | XF-SRX8          |
| 9    | slide hook pin    | 1    | SRX8-L95-L4      | SRX8-L100-L4     | SRX8-L105-L4     |
| 10   | roll pin          | 1    | XA4-25           | XA4-25           | XA4-25           |
| 11   | slide upper       | 1    | SRX8-L95-L8      | SRX8-L100-L8     | SRX8-L105-L8     |
| 12   | slide bottom      | 1    | SRX8-L95-L10     | SRX8-L100-L10    | SRX8-L105-L10    |
| 13   | fixed pin         | 2    | SRX8-L95-L11     | SRX8-L100-L11    | SRX8-L105-L11    |
| * 14 | CAP bolt          | 4    | XNCAP1/4"-5/8"   | XNCAP1/4"-5/8"   | XNCAP1/4"-5/8"   |
| * 15 | countersink       | 4    | XNFF3/8"-1"      | XNFF3/8"-1"      | XNFF3/8"-1"      |
| * 16 | oval head bolt    | 2    | XNBH#10-32-3/8   | XNBH#10-32-3/8   | XNBH#10-32-3/8   |
| 17   | shroud            | 1    | SRX8-L95-L13     | SRX8-L100-L13    | SRX8-L105-L13    |


\* Repair Kit

|      |                   |      | SRX-8 L50        | SRX-8 L55        | SRX-8 L60        | SRX-8 L65        | SRX-8 L70        | SRX-8 L75        | SRX-8 L80        | SRX-8 L85        | SRX-8 L90        |
|------|-------------------|------|------------------|------------------|------------------|------------------|------------------|------------------|------------------|------------------|------------------|
| Item | product           | Q'ty | Part No.         | Part No.         | Part No.         | Part No.         | Part No.         | Part No.         | Part No.         | Part No.         | Part No.         |
| 1    | side plate-R      | 1    | SRX8-L50-L1-1    | SRX8-L55-L1-1    | SRX8-L60-L1-1    | SRX8-L65-L1-1    | SRX8-L70-L1-1    | SRX8-L75-L1-1    | SRX8-L80-L1-1    | SRX8-L85-L1-1    | SRX8-L90-L1-1    |
| 2    | side plate-L      | 1    | SRX8-L50-L1-2    | SRX8-L55-L1-2    | SRX8-L60-L1-2    | SRX8-L65-L1-2    | SRX8-L70-L1-2    | SRX8-L75-L1-2    | SRX8-L80-L1-2    | SRX8-L85-L1-2    | SRX8-L90-L1-2    |
| 3    | copper ring       | 2    | SRX8-L50-L12     | SRX8-L55-L12     | SRX8-L60-L12     | SRX8-L65-L12     | SRX8-L70-L12     | SRX8-L75-L12     | SRX8-L80-L12     | SRX8-L85-L12     | SRX8-L90-L12     |
| 4    | bronze sleeve     | 1    | SRX8-L50-L3      | SRX8-L55-L3      | SRX8-L60-L3      | SRX8-L65-L3      | SRX8-L70-L3      | SRX8-L75-L3      | SRX8-L80-L3      | SRX8-L85-L3      | SRX8-L90-L3      |
| 5    | reatchet          | 1    | SRX8-L50-L6      | SRX8-L55-L6      | SRX8-L60-L6      | SRX8-L65-L6      | SRX8-L70-L6      | SRX8-L75-L6      | SRX8-L80-L6      | SRX8-L85-L6      | SRX8-L90-L6      |
| 6    | drive pawl        | 1    | SRX8-L50-L7      | SRX8-L55-L7      | SRX8-L60-L7      | SRX8-L65-L7      | SRX8-L70-L7      | SRX8-L75-L7      | SRX8-L80-L7      | SRX8-L85-L7      | SRX8-L90-L7      |
| 7    | drive pawl spring | 1    | XF0.8-D6.2-10-8T | XF0.8-D6.2-10-8T | XF0.8-D6.2-10-8T | XF0.8-D6.2-10-8T | XF0.8-D6.2-10-8T | XF0.8-D6.2-10-8T | XF0.8-D6.2-10-8T | XF0.8-D6.2-10-8T | XF0.8-D6.2-10-8T |
| 8    | reaction spring   | 1    | XF-SRX8          | XF-SRX8          | XF-SRX8          | XF-SRX8          | XF-SRX8          | XF-SRX8          | XF-SRX8          | XF-SRX8          | XF-SRX8          |
| 9    | slide hook pin    | 1    | SRX8-L50-L4      | SRX8-L55-L4      | SRX8-L60-L4      | SRX8-L65-L4      | SRX8-L70-L4      | SRX8-L75-L4      | SRX8-L80-L4      | SRX8-L85-L4      | SRX8-L90-L4      |
| 10   | roll pin          | 1    | XA4-25           | XA4-25           | XA4-25           | XA4-25           | XA4-25           | XA4-25           | XA4-25           | XA4-25           | XA4-25           |
| 11   | slide upper       | 1    | SRX8-L50-L8      | SRX8-L55-L8      | SRX8-L60-L8      | SRX8-L65-L8      | SRX8-L70-L8      | SRX8-L75-L8      | SRX8-L80-L8      | SRX8-L85-L8      | SRX8-L90-L8      |
| 12   | slide bottom      | 1    | SRX8-L50-L10     | SRX8-L55-L10     | SRX8-L60-L10     | SRX8-L65-L10     | SRX8-L70-L10     | SRX8-L75-L10     | SRX8-L80-L10     | SRX8-L85-L10     | SRX8-L90-L10     |
| 13   | fixed pin         | 2    | SRX8-L50-L11     | SRX8-L55-L11     | SRX8-L60-L11     | SRX8-L65-L11     | SRX8-L70-L11     | SRX8-L75-L11     | SRX8-L80-L11     | SRX8-L85-L11     | SRX8-L90-L11     |
| * 14 | CAP bolt          | 4    | XNCAP1/4"-5/8"   | XNCAP1/4"-5/8"   | XNCAP1/4"-5/8"   | XNCAP1/4"-5/8"   | XNCAP1/4"-5/8"   | XNCAP1/4"-5/8"   | XNCAP1/4"-5/8"   | XNCAP1/4"-5/8"   | XNCAP1/4"-5/8"   |
| * 15 | countersink       | 4    | XNFF3/8"-1"      | XNFF3/8"-1"      | XNFF3/8"-1"      | XNFF3/8"-1"      | XNFF3/8"-1"      | XNFF3/8"-1"      | XNFF3/8"-1"      | XNFF3/8"-1"      | XNFF3/8"-1"      |
| * 16 | oval head bolt    | 2    | XNBH#10-32-3/8   | XNBH#10-32-3/8   | XNBH#10-32-3/8   | XNBH#10-32-3/8   | XNBH#10-32-3/8   | XNBH#10-32-3/8   | XNBH#10-32-3/8   | XNBH#10-32-3/8   | XNBH#10-32-3/8   |
| 17   | shroud            | 1    | SRX8-L50-L13     | SRX8-L55-L13     | SRX8-L60-L13     | SRX8-L65-L13     | SRX8-L70-L13     | SRX8-L75-L13     | SRX8-L80-L13     | SRX8-L85-L13     | SRX8-L90-L13     |

\* Repair Kit



Chu Lun Sing Co.,Ltd




| Item | Part                  | Q'ty | Part No.           |
|------|-----------------------|------|--------------------|
| 1    | Housing assembly      | 1    | SRX16-C01          |
| 2    | plunger               | 1    | SRX16-C02          |
| 3    | piston                | 1    | SRX16-C03          |
| 4    | end cap               | 1    | SRX16-C07          |
| * 5  | back-up ring          | 1    | XGAS328            |
| * 6  | O-ring                | 1    | XBAS328-90-NOK     |
| * 7  | O-ring                | 1    | XABAS226-NOK       |
| * 8  | back-up ring          | 1    | XAGAS226           |
| * 9  | seal                  | 1    | XEISI35            |
| 10   | half-moon pusher      | 2    | SRX16-C04          |
| 11   | spring plug           | 1    | XA06-35            |
| 12   | steel ball            | 1    | XM1/4              |
| 13   | bolt                  | 1    | XNSETM8-16         |
| 14   | plug                  | 1    | XNPT1/8            |
| 15   | swivel assembly       | 1    | SMX10-A00-1-USA    |
| 16   | bolt                  | 5    | XNCAPM6-20         |
| 17   | in/ out base assembly | 1    | SMX10-A00-4-USA    |
| 18   | C type ring           | 1    | XAS019             |
| * 19 | back-up ring          | 4    | XGP020             |
| * 20 | O-ring                | 3    | XBP020-PU          |
| * 21 | O-ring                | 2    | XBP006-90-NOK      |
| * 22 | back-up ring          | 2    | XGP006             |
| 23   | plug                  | 1    | SMX10-A00-5-USA    |
| 24   | bolt                  | 1    | SETM06-12          |
| 25   | spring                | 1    | XF0.8-D4.6-12L-6T= |
| 26   | steel ball            | 1    | XM3/16             |

\* repair kit

Instructions for:  
Double-Acting, Hexgon Cassette Torque Wrench

Model : SRX-16  
SRX-16L Link



| Item | Part              | Q'ty | SRX-16 L70            | SRX-16 L75            | SRX-16 L80            | SRX-16 L85            |
|------|-------------------|------|-----------------------|-----------------------|-----------------------|-----------------------|
|      |                   |      | Part No.              | Part No.              | Part No.              | Part No.              |
| 1    | side plate-R      | 1    | SRX16-L70-L1          | SRX16-L75-L1          | SRX16-L80-L1          | SRX16-L85-L1          |
| 2    | side plate-L      | 1    | SRX16-L70-L2          | SRX16-L75-L2          | SRX16-L80-L2          | SRX16-L85-L2          |
| 3    | bronze sleeve     | 1    | SRX16-L70-L3          | SRX16-L75-L3          | SRX16-L80-L3          | SRX16-L85-L3          |
| 4    | reatchet          | 1    | SRX16-L70-L6          | SRX16-L75-L6          | SRX16-L80-L6          | SRX16-L85-L6          |
| 5    | drive pawl        | 1    | SRX16-L70-L7          | SRX16-L75-L7          | SRX16-L80-L7          | SRX16-L85-L7          |
| 6    | slide middle      | 1    | SRX16-L70-L9          | SRX16-L75-L9          | SRX16-L80-L9          | SRX16-L85-L9          |
| 7    | slide upper       | 1    | SRX16-L70-L8          | SRX16-L75-L8          | SRX16-L80-L8          | SRX16-L85-L8          |
| 8    | slide hook pin    | 1    | SRX16-L70-L4          | SRX16-L75-L4          | SRX16-L80-L4          | SRX16-L85-L4          |
| 9    | spring            | 1    | XF1.2-D11.7-18.7L-5T= | XF1.2-D11.7-18.7L-5T= | XF1.2-D11.7-18.7L-5T= | XF1.2-D11.7-18.7L-5T= |
| 10   | roll pin          | 1    | XA3/8-2 1/2           | XA3/8-2 1/2           | XA3/8-2 1/2           | XA3/8-2 1/2           |
| 11   | reaction spring   | 1    | SRX16-L5              | SRX16-L5              | SRX16-L5              | SRX16-L5              |
| 12   | roll pin          | 1    | XA1/4-1 1/2           | XA1/4-1 1/2           | XA1/4-1 1/2           | XA1/4-1 1/2           |
| 13   | slide bottom      | 1    | SRX16-L70-L10         | SRX16-L75-L10         | SRX16-L80-L10         | SRX16-L85-L10         |
| 14   | copper ring       | 2    | SRX16-L70-L13         | SRX16-L75-L13         | SRX16-L80-L13         | SRX16-L85-L13         |
| 15   | slide bottom plug | 2    | SRX16-L70-L11         | SRX16-L75-L11         | SRX16-L80-L11         | SRX16-L85-L11         |
| 16   | shroud            | 1    | SRX16-L70-L14         | SRX16-L75-L14         | SRX16-L80-L14         | SRX16-L85-L14         |
| 17   | oval head bolt    | 2    | XNHB1/4-3/8           | XNHB1/4-3/8           | XNHB1/4-3/8           | XNHB1/4-3/8           |
| 18   | countersink       | 4    | XNF5/8-1 1/4          | XNF5/8-1 1/4          | XNF5/8-1 1/4          | XNF5/8-1 1/4          |
| 19   | CAP bolt          | 4    | XNCAP3/8-1"           | XNCAP3/8-1"           | XNCAP3/8-1"           | XNCAP3/8-1"           |

\* Repair Kit


| Item | Part              | Q'ty | SRX-16 L90            | SRX-16 L95            | SRX-16 L100           | SRX-16 L105           |
|------|-------------------|------|-----------------------|-----------------------|-----------------------|-----------------------|
|      |                   |      | Part No.              | Part No.              | Part No.              | Part No.              |
| 1    | side plate-R      | 1    | SRX16-L90-L1          | SRX16-L95-L1          | SRX16-L100-L1         | SRX16-L105-L1         |
| 2    | side plate-L      | 1    | SRX16-L90-L2          | SRX16-L95-L2          | SRX16-L100-L2         | SRX16-L105-L2         |
| 3    | bronze sleeve     | 1    | SRX16-L90-L3          | SRX16-L95-L3          | SRX16-L100-L3         | SRX16-L105-L3         |
| 4    | reatchet          | 1    | SRX16-L90-L6          | SRX16-L95-L6          | SRX16-L100-L6         | SRX16-L105-L6         |
| 5    | drive pawl        | 1    | SRX16-L90-L7          | SRX16-L95-L7          | SRX16-L100-L7         | SRX16-L105-L7         |
| 6    | slide middle      | 1    | SRX16-L90-L9          | SRX16-L95-L9          | SRX16-L100-L9         | SRX16-L105-L9         |
| 7    | slide upper       | 1    | SRX16-L90-L8          | SRX16-L95-L8          | SRX16-L100-L8         | SRX16-L105-L8         |
| 8    | slide hook pin    | 1    | SRX16-L90-L4          | SRX16-L95-L4          | SRX16-L100-L4         | SRX16-L105-L4         |
| 9    | spring            | 1    | XF1.2-D11.7-18.7L-5T= | XF1.2-D11.7-18.7L-5T= | XF1.2-D11.7-18.7L-5T= | XF1.2-D11.7-18.7L-5T= |
| 10   | roll pin          | 1    | XA3/8-2 1/2           | XA3/8-2 1/2           | XA3/8-2 1/2           | XA3/8-2 1/2           |
| 11   | reaction spring   | 1    | SRX16-L5              | SRX16-L5              | SRX16-L5              | SRX16-L5              |
| 12   | roll pin          | 1    | XA1/4-1 1/2           | XA1/4-1 1/2           | XA1/4-1 1/2           | XA1/4-1 1/2           |
| 13   | slide bottom      | 1    | SRX16-L90-L10         | SRX16-L95-L10         | SRX16-L100-L10        | SRX16-L105-L10        |
| 14   | copper ring       | 2    | SRX16-L90-L13         | SRX16-L95-L13         | SRX16-L100-L13        | SRX16-L105-L13        |
| 15   | slide bottom plug | 2    | SRX16-L90-L11         | SRX16-L95-L11         | SRX16-L100-L11        | SRX16-L105-L11        |
| 16   | shroud            | 1    | SRX16-L90-L14         | SRX16-L95-L14         | SRX16-L100-L14        | SRX16-L105-L14        |
| 17   | oval head bolt    | 2    | XNHB1/4-3/8           | XNHB1/4-3/8           | XNHB1/4-3/8           | XNHB1/4-3/8           |
| 18   | countersink       | 4    | XNF5/8-1 1/4          | XNF5/8-1 1/4          | XNF5/8-1 1/4          | XNF5/8-1 1/4          |
| 19   | CAP bolt          | 4    | XNCAP3/8-1"           | XNCAP3/8-1"           | XNCAP3/8-1"           | XNCAP3/8-1"           |

\* Repair Kit

| Item | Part              | Q'ty | SRX-16 L110           | SRX-16 L115           |
|------|-------------------|------|-----------------------|-----------------------|
|      |                   |      | Part No.              | Part No.              |
| 1    | side plate-R      | 1    | SRX16-L110-L1         | SRX16-L115-L1         |
| 2    | side plate-L      | 1    | SRX16-L110-L2         | SRX16-L115-L2         |
| 3    | bronze sleeve     | 1    | SRX16-L110-L3         | SRX16-L115-L3         |
| 4    | reatchet          | 1    | SRX16-L110-L6         | SRX16-L115-L6         |
| 5    | drive pawl        | 1    | SRX16-L110-L7         | SRX16-L115-L7         |
| 6    | slide middle      | 1    | SRX16-L110-L9         | SRX16-L115-L9         |
| 7    | slide upper       | 1    | SRX16-L110-L8         | SRX16-L115-L8         |
| 8    | slide hook pin    | 1    | SRX16-L110-L4         | SRX16-L115-L4         |
| 9    | spring            | 1    | XF1.2-D11.7-18.7L-5T= | XF1.2-D11.7-18.7L-5T= |
| 10   | roll pin          | 1    | XA3/8-2 1/2           | XA3/8-2 1/2           |
| 11   | reaction spring   | 1    | SRX16-L5              | SRX16-L5              |
| 12   | roll pin          | 1    | XA1/4-1 1/2           | XA1/4-1 1/2           |
| 13   | slide bottom      | 1    | SRX16-L110-L10        | SRX16-L115-L10        |
| 14   | copper ring       | 2    | SRX16-L110-L13        | SRX16-L115-L13        |
| 15   | slide bottom plug | 2    | SRX16-L110-L11        | SRX16-L115-L11        |
| 16   | shroud            | 1    | SRX16-L110-L14        | SRX16-L115-L14        |
| 17   | oval head bolt    | 2    | XNHB1/4-3/8           | XNHB1/4-3/8           |
| 18   | countersink       | 4    | XNF5/8-1 1/4          | XNF5/8-1 1/4          |
| 19   | CAP bolt          | 4    | XNCAP3/8-1"           | XNCAP3/8-1"           |

\* Repair Kit






| Item | Part             | Q'ty | Part No.           |
|------|------------------|------|--------------------|
| 1    | Housing assembly | 1    | SRX32-C01          |
| 2    | plunger          | 1    | SRX32-C02          |
| * 3  | back-up ring     | 2    | XGAS333            |
| * 4  | O-ring           | 2    | XBAS333            |
| 5    | end cap          | 1    | SRX32-C07          |
| * 6  | O-ring           | 1    | XBAS326            |
| * 7  | back-up ring     | 1    | XGAS326            |
| 8    | half-moon pusher | 2    | SRX32-C06          |
| 9    | spring plug      | 1    | XA08-45            |
| 10   | plug             | 1    | SMX10-A00-5-USA    |
| 11   | swivel assembly  | 1    | SMX10-A00-1-USA    |
| 12   | bolt             | 5    | XNCAPM6-20         |
| * 13 | O-ring           | 3    | XBP20-PU           |
| * 14 | back-up ring     | 4    | XGP20              |
| 15   | in/ out base     | 1    | SMX10-A00-4-USA    |
| 16   | C type ring      | 1    | XAS019             |
| 17   | bolt             | 1    | SETM06-12          |
| 18   | spring           | 1    | XF0.8-D4.6-12L-6T= |
| 19   | steel ball       | 1    | XM3/16             |
| * 20 | back-up ring     | 4    | XGAS015            |
| * 21 | O-ring           | 4    | XBPAS015-PU        |

\* repair kit

# Instructions for: Double-Acting, Hexgon Cassette Torque Wrench

Model : SRX-32  
SRX-32L Link



|      |                   |      | SRX-32 L80        | SRX-32 L85        | SRX-32 L90        |
|------|-------------------|------|-------------------|-------------------|-------------------|
| Item | Part              | Q'ty | Part No.          | Part No.          | Part No.          |
| 1    | side plate-R      | 1    | SRX32-L80-L1      | SRX32-L85-L1      | SRX32-L90-L1      |
| 2    | side plate-L      | 1    | SRX32-L80-L2      | SRX32-L85-L2      | SRX32-L90-L2      |
| 3    | copper ring       | 2    | SRX32-L80-L12     | SRX32-L85-L12     | SRX32-L90-L12     |
| 4    | bronze sleeve     | 1    | SRX32-L80-L3      | SRX32-L85-L3      | SRX32-L90-L3      |
| 5    | reatchet          | 1    | SRX32-L80-L6      | SRX32-L85-L6      | SRX32-L90-L6      |
| 6    | drive pawl        | 1    | SRX32-L80-L7      | SRX32-L85-L7      | SRX32-L90-L7      |
| 7    | drive pawl spring | 2    | SRX32-L80-L14     | SRX32-L85-L14     | SRX32-L90-L14     |
| 8    | reaction spring   | 1    | SRX32-L80-L5      | SRX32-L85-L5      | SRX32-L90-L5      |
| 9    | slide hook pin    | 1    | SRX32-L80-L4      | SRX32-L85-L4      | SRX32-L90-L4      |
| 10   | roll pin          | 1    | XA2/8x1-1/4L      | XA2/8x1-1/4L      | XA2/8x1-1/4L      |
| 11   | slide upper       | 1    | SRX32-L80-L8      | SRX32-L85-L8      | SRX32-L90-L8      |
| 12   | slide bottom      | 1    | SRX32-L80-L10     | SRX32-L85-L10     | SRX32-L90-L10     |
| 13   | fixed pin         | 2    | SRX32-L80-L11     | SRX32-L85-L11     | SRX32-L90-L11     |
| * 14 | CAP bolt          | 4    | XNCAP3/8-10x1L    | XNCAP3/8-10x1L    | XNCAP3/8-10x1L    |
| * 15 | countersink       | 4    | XNF5/8-11x7/8L    | XNF5/8-11x7/8L    | XNF5/8-11x7/8L    |
| * 16 | oval head bolt    | 2    | XNBH1/4-20x11/32L | XNBH1/4-20x11/32L | XNBH1/4-20x11/32L |
| 17   | shroud            | 1    | SRX32-L80-L13     | SRX32-L85-L13     | SRX32-L90-L13     |

\* Repair Kit

|      |                   |      | SRX-32 L95        | SRX-32 L100       | SRX-32 L105       |
|------|-------------------|------|-------------------|-------------------|-------------------|
| Item | Part              | Q'ty | Part No.          | Part No.          | Part No.          |
| 1    | side plate-R      | 1    | SRX32-L95-L1      | SRX32-L100-L1     | SRX32-L105-L1     |
| 2    | side plate-L      | 1    | SRX32-L95-L2      | SRX32-L100-L2     | SRX32-L105-L2     |
| 3    | copper ring       | 2    | SRX32-L95-L12     | SRX32-L100-L12    | SRX32-L105-L12    |
| 4    | bronze sleeve     | 1    | SRX32-L95-L3      | SRX32-L100-L3     | SRX32-L105-L3     |
| 5    | reatchet          | 1    | SRX32-L95-L6      | SRX32-L100-L6     | SRX32-L105-L6     |
| 6    | drive pawl        | 1    | SRX32-L95-L7      | SRX32-L100-L7     | SRX32-L105-L7     |
| 7    | drive pawl spring | 2    | SRX32-L95-L14     | SRX32-L100-L14    | SRX32-L105-L14    |
| 8    | reaction spring   | 1    | SRX32-L95-L5      | SRX32-L100-L5     | SRX32-L105-L5     |
| 9    | slide hook pin    | 1    | SRX32-L95-L4      | SRX32-L100-L4     | SRX32-L105-L4     |
| 10   | roll pin          | 1    | XA2/8x1-1/4L      | XA2/8x1-1/4L      | XA2/8x1-1/4L      |
| 11   | slide upper       | 1    | SRX32-L95-L8      | SRX32-L100-L8     | SRX32-L105-L8     |
| 12   | slide bottom      | 1    | SRX32-L95-L10     | SRX32-L100-L10    | SRX32-L105-L10    |
| 13   | fixed pin         | 2    | SRX32-L95-L11     | SRX32-L100-L11    | SRX32-L105-L11    |
| * 14 | CAP bolt          | 4    | XNCAP3/8-10x1L    | XNCAP3/8-10x1L    | XNCAP3/8-10x1L    |
| * 15 | countersink       | 4    | XNF5/8-11x7/8L    | XNF5/8-11x7/8L    | XNF5/8-11x7/8L    |
| * 16 | oval head bolt    | 2    | XNBH1/4-20x11/32L | XNBH1/4-20x11/32L | XNBH1/4-20x11/32L |
| 17   | shroud            | 1    | SRX32-L95-L13     | SRX32-L100-L13    | SRX32-L105-L13    |

\* Repair Kit

|      |                   |      | SRX-32 L110       | SRX-32 L115       | SRX-32 L117       | SRX-32 L120       | SRX-32 L125       | SRX-32 L130       | SRX-32 L135       | SRX-32 L140       | SRX-32 L145       | SRX-32 L150       | SRX-32 L155       |
|------|-------------------|------|-------------------|-------------------|-------------------|-------------------|-------------------|-------------------|-------------------|-------------------|-------------------|-------------------|-------------------|
| Item | Part              | Q'ty | Part No.          | Part No.          | Part No.          | Part No.          | Part No.          | Part No.          | Part No.          | Part No.          | Part No.          | Part No.          | Part No.          |
| 1    | side plate-R      | 1    | SRX32-L110-L1     | SRX32-L115-L1     | SRX32-L117-L1     | SRX32-L120-L1     | SRX32-L125-L1     | SRX32-L130-L1     | SRX32-L135-L1     | SRX32-L140-L1     | SRX32-L145-L1     | SRX32-L150-L1     | SRX32-L155-L1     |
| 2    | side plate-L      | 1    | SRX32-L110-L2     | SRX32-L115-L2     | SRX32-L117-L2     | SRX32-L120-L2     | SRX32-L125-L2     | SRX32-L130-L2     | SRX32-L135-L2     | SRX32-L140-L2     | SRX32-L145-L2     | SRX32-L150-L2     | SRX32-L155-L2     |
| 3    | copper ring       | 2    | SRX32-L110-L12    | SRX32-L115-L12    | SRX32-L117-L12    | SRX32-L120-L12    | SRX32-L125-L12    | SRX32-L130-L12    | SRX32-L135-L12    | SRX32-L140-L12    | SRX32-L145-L12    | SRX32-L150-L12    | SRX32-L155-L12    |
| 4    | bronze sleeve     | 1    | SRX32-L110-L3     | SRX32-L115-L3     | SRX32-L117-L3     | SRX32-L120-L3     | SRX32-L125-L3     | SRX32-L130-L3     | SRX32-L135-L3     | SRX32-L140-L3     | SRX32-L145-L3     | SRX32-L150-L3     | SRX32-L155-L3     |
| 5    | reatchet          | 1    | SRX32-L110-L6     | SRX32-L115-L6     | SRX32-L117-L6     | SRX32-L120-L6     | SRX32-L125-L6     | SRX32-L130-L6     | SRX32-L135-L6     | SRX32-L140-L6     | SRX32-L145-L6     | SRX32-L150-L6     | SRX32-L155-L6     |
| 6    | drive pawl        | 1    | SRX32-L110-L7     | SRX32-L115-L7     | SRX32-L117-L7     | SRX32-L120-L7     | SRX32-L125-L7     | SRX32-L130-L7     | SRX32-L135-L7     | SRX32-L140-L7     | SRX32-L145-L7     | SRX32-L150-L7     | SRX32-L155-L7     |
| 7    | drive pawl spring | 1    | SRX32-L110-L14    | SRX32-L115-L14    | SRX32-L117-L14    | SRX32-L120-L14    | SRX32-L125-L14    | SRX32-L130-L14    | SRX32-L135-L14    | SRX32-L140-L14    | SRX32-L145-L14    | SRX32-L150-L14    | SRX32-L155-L14    |
| 8    | reaction spring   | 1    | SRX32-L110-L5     | SRX32-L115-L5     | SRX32-L117-L5     | SRX32-L120-L5     | SRX32-L125-L5     | SRX32-L130-L5     | SRX32-L135-L5     | SRX32-L140-L5     | SRX32-L145-L5     | SRX32-L150-L5     | SRX32-L155-L5     |
| 9    | slide hook pin    | 1    | SRX32-L110-L4     | SRX32-L115-L4     | SRX32-L117-L4     | SRX32-L120-L4     | SRX32-L125-L4     | SRX32-L130-L4     | SRX32-L135-L4     | SRX32-L140-L4     | SRX32-L145-L4     | SRX32-L150-L4     | SRX32-L155-L4     |
| 10   | roll pin          | 1    | XA2/8x1-1/4L      | XA2/8x1-1/4L      | XA2/8x1-1/4L      | XA2/8x1-1/4L      | XA2/8x1-1/4L      | XA2/8x1-1/4L      | XA2/8x1-1/4L      | XA2/8x1-1/4L      | XA2/8x1-1/4L      | XA2/8x1-1/4L      | XA2/8x1-1/4L      |
| 11   | slide upper       | 1    | SRX32-L110-L8     | SRX32-L115-L8     | SRX32-L117-L8     | SRX32-L120-L8     | SRX32-L125-L8     | SRX32-L130-L8     | SRX32-L135-L8     | SRX32-L140-L8     | SRX32-L145-L8     | SRX32-L150-L8     | SRX32-L155-L8     |
| 12   | slide bottom      | 1    | SRX32-L110-L10    | SRX32-L115-L10    | SRX32-L117-L10    | SRX32-L120-L10    | SRX32-L125-L10    | SRX32-L130-L10    | SRX32-L135-L10    | SRX32-L140-L10    | SRX32-L145-L10    | SRX32-L150-L10    | SRX32-L155-L10    |
| 13   | fixed pin         | 2    | SRX32-L110-L11    | SRX32-L115-L11    | SRX32-L117-L11    | SRX32-L120-L11    | SRX32-L125-L11    | SRX32-L130-L11    | SRX32-L135-L11    | SRX32-L140-L11    | SRX32-L145-L11    | SRX32-L150-L11    | SRX32-L155-L11    |
| * 14 | CAP bolt          | 4    | XNCAP3/8-10x1L    | XNCAP3/8-10x1L    | XNCAP3/8-10x1L    | XNCAP3/8-10x1L    | XNCAP3/8-10x1L    | XNCAP3/8-10x1L    | XNCAP3/8-10x1L    | XNCAP3/8-10x1L    | XNCAP3/8-10x1L    | XNCAP3/8-10x1L    | XNCAP3/8-10x1L    |
| * 15 | countersink       | 4    | XNF5/8-11x7/8L    | XNF5/8-11x7/8L    | XNF5/8-11x7/8L    | XNF5/8-11x7/8L    | XNF5/8-11x7/8L    | XNF5/8-11x7/8L    | XNF5/8-11x7/8L    | XNF5/8-11x7/8L    | XNF5/8-11x7/8L    | XNF5/8-11x7/8L    | XNF5/8-11x7/8L    |
| * 16 | oval head bolt    | 2    | XNBH1/4-20x11/32L | XNBH1/4-20x11/32L | XNBH1/4-20x11/32L | XNBH1/4-20x11/32L | XNBH1/4-20x11/32L | XNBH1/4-20x11/32L | XNBH1/4-20x11/32L | XNBH1/4-20x11/32L | XNBH1/4-20x11/32L | XNBH1/4-20x11/32L | XNBH1/4-20x11/32L |
| 17   | shroud            | 1    | SRX32-L110-L13    | SRX32-L115-L13    | SRX32-L117-L13    | SRX32-L120-L13    | SRX32-L125-L13    | SRX32-L130-L13    | SRX32-L135-L13    | SRX32-L140-L13    | SRX32-L145-L13    | SRX32-L150-L13    | SRX32-L155-L13    |

\* Repair Kit



Chu Lun Sing Co.,Ltd